



LMP-1002C-SFP Series

**10-Port Industrial PoE+ Gigabit Managed Ethernet Switches
8*10/100Tx (30W/Port), 2*Gigabit Combo Ports (w/2*10/100/1000Tx RJ45
and 2*100/1000 SFP Slots)**



User Manual

Version 1.0



© Copyright 2015 Antaira Technologies, LLC

All Rights Reserved

This document contains information, which is protected by copyright. Reproduction, adaptation or translation without prior permission is prohibited, except as allowed under the copyright laws.

Trademark Information

Antaira is a registered trademark of Antaira Technologies, LLC, Microsoft Windows and the Windows logo are the trademarks of Microsoft Corp. NetWare is the registered trademark of Novell Inc. WMM and WPA are the registered trademarks of Wi-Fi Alliance. All other brand and product names are trademarks or registered trademarks of their respective owners.

Notice: Copyrights © 2015 by Antaira Technologies, LLC. All rights reserved. Reproduction, adaptation, or translation without prior permission of Antaira Technologies, LLC is prohibited, except as allowed under the copyright laws.

Disclaimer

Antaira Technologies, LLC provides this manual without warranty of any kind, expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Antaira Technologies, LLC may make improvements and/or changes to the product and/or specifications of the product described in this manual, without prior notice. Antaira Technologies, LLC will not be liable for any technical inaccuracies or typographical errors found in this guide. Changes are periodically made to the information contained herein and will be incorporated into later versions of the manual. The information contained is subject to change without prior notice.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class-A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. It may cause harmful interference to radio communications if the equipment is not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

CE Mark Warning

This is a Class-A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Industrial Ethernet Switches

Industrial Grade Gigabit PoE Managed Ethernet Switches

User Manual

Version 1.0 (August 2015)

This manual supports the following models:

- LMP-1002C-SFP
- LMP-1002C-SFP-T

This document is the current official release manual. Please check our website (www.antaira.com) for any updated manual or contact us by e-mail (support@antaira.com).

Table of Contents

1. Introduction	1
1.1 Product Overview.....	1
1.2 Product Software Features.....	1
1.3 Product Hardware Features.....	2
1.4 Package Contents.....	3
1.5 Safety Precaution.....	3
2. Hardware Description.....	4
2.1 Physical Dimensions.....	4
2.2 Front Panel.....	5
2.3 Top View	5
2.4 LED Indicators.....	6
2.5 Reset Button.....	6
2.6 Ethernet Ports.....	7
2.7 Cabling	8
2.7.1 Gigabit Combo Port - Copper/SFP (Mini-GBIC)	8
2.8 Wiring the Power Inputs.....	11
2.9 Wiring the Fault Alarm Contact.....	11
3. Mounting Installation	12
3.1 DIN-Rail Mounting.....	12
3.2 Wall Mounting.....	13
4. Hardware Installation	14
4.1 Installation Steps.....	14
5. Web Management.....	15
5.1 Web Console Configuration.....	15
5.1.1 About Web-Based Management	15

5.2 Basic Setting.....	16
5.2.1 System Information	16
5.2.2 Admin & Password	17
5.2.3 IP Setting.....	18
5.2.4 IPv6 Neighbor Cache	19
5.2.5 IPv6 Settings	19
5.2.6 System Time	20
5.3 Port Management.....	21
5.3.1 Port Status.....	21
5.3.2 Port Configuration	21
5.4 PoE (Power-over-Ethernet)	22
5.4.1 PoE Configuration	22
5.4.2 Ping Alarm.....	23
5.4.3 PoE Schedule.....	24
5.5 ERPS	25
5.5.1 ERPS Status	26
5.5.2 ERPS Configuration	26
5.5.3 Before Configuring ERPS.....	28
5.6 Spanning Tree	36
5.6.1 RSTP Status.....	36
5.6.2 RSTP Configuration	37
5.6.3 MSTI Status.....	39

5.6.4 MSTI Configuration	39
5.7 IGMP Snooping.....	41
5.7.1 IGMP Settings	42
5.7.2 IGMP Snooping Status Table	42
5.8 802.1Q VLAN.....	43
5.8.1 802.1Q VLAN Settings.....	43
5.8.2 802.1Q VLAN Port Settings	44
5.9 QoS (Traffic Prioritization)	45
5.9.1 QoS Classification	46
5.9.2 CoS Mapping.....	47
5.9.3 ToS Mapping	48
5.10 Port Trunk.....	49
5.10.1 Trunk Status	49
5.10.2 Trunk Configuration	50
5.11 Port Mirroring.....	51
5.12 SNMP	52
5.12.1 SNMP Agent.....	52
5.12.2 SNMP Trap Setting	54
5.13 DHCP Server / Rely.....	55
5.13.1 DHCP Client.....	56
5.13.2 DHCP Server.....	57
5.13.3 DHCP Server Binding.....	58

5.13.4 DHCP Relay	59
5.14 802.1X	60
5.14.1 802.1X Settings	60
5.14.2 Local Database.....	61
5.14.3 RADIUS Server	62
5.15 UPnP	63
5.15.3 UPnP	63
5.16 Modbus TCP.....	64
5.16.1 Enable Modbus TCP	64
5.16.2 MODBUS Data Map and Information	64
5.17 System Warning.....	70
5.17.1 Syslog Setting	70
5.17.2 System Event Log.....	71
5.17.3 SMTP Setting	72
5.17.4 Event Selection	73
5.17.5 Fault Alarm.....	73
5.18 MAC Table.....	74
5.18.1 MAC Address Table	74
5.18.2 MAC Table Configuration	74
5.19 Maintenance.....	75
5.19.1 Upgrade.....	75
5.19.2 Reboot.....	75

5.19.3 Default	76
5.20 Configuration	76
5.20.1 Save	76
5.20.2 Backup & Store	77
5.20.3 Auto Load & Backup.....	78
5.21 Logout	78
6. Command Line Interface Management	79
6.1 About CLI Management.....	79
7. Technical Specifications	97

1. Introduction

All Antaira industrial managed switches come with a pre-installed “user friendly” web console interface, which allows users to easily configure and manage the units, whether one is using a serial console and command line interface (CLI) commands like Telnet, SSH, HTTP (Web GUI) or simple network management protocols (SNMP).

1.1 Product Overview

Antaira’s LMP-1002C-SFP series is a 10-port industrial Gigabit PoE+ managed Ethernet switch that is embedded with 8*10/100Tx Ethernet ports that support IEEE802.3at/af for a maximum of 30W/port, and 2*Gigabit combo ports with 2*10/100/1000Tx RJ45 or 2*100/1000 dual rate SFP slots for Gigabit fiber connections. The Gigabit combo ports provide flexibility to users for either a 10/100 or 1000Tx Fast Ethernet or a plug in SFP key module with a 100MB or Gigabit fiber connection. The combo ports help achieve bandwidth and/or distance concern applications. The LMP-1002C-SFP series is a fully manageable Layer 2 Ethernet switch that is pre-loaded with a user-friendly web management console design. It supports the ring network redundancy function using the market’s open standard ITU-T G.8032 ERPS (Ethernet Ring Protection Switch) protocol that has a <50ms network recovery time. The advanced network filtering and security functions, such as, IGMP, VLAN, QoS, SNMP, port lock, RMON, ModbusTCP, and 802.1X/HTTPS/SSH/SSL increase determinism and improve network management for remote SCADA systems or control networks.

The LMP-1002C-SFP series is IP30 rated and DIN-rail mountable. There are also two wide operating temperature models for either a standard temperature range (STD: -10°C to 70°C) or an extended temperature range (EOT: -40°C to 75°C). It also provides high EFT and ESD protection for industrial networking applications, such as, power/utility, water wastewater, oil/gas/mining, factory automation, security surveillance within transportation, ITS and any other outdoor or harsh environment.

1.2 Product Software Features

- Network Redundancy
 - STP, RSTP, MSTP, ITU-T G.8032 Ethernet Ring Protection Switch (ERPS) for network redundancy
- Network Management
 - Web UI based management, SNMP v1/v2/v3, Serial Console
 - Qos, traffic classification QoS, Cos, bandwidth control for Ingress and Egress,

- broadcast storm control, Diffserv
- IEEE802.1q VLAN tagging, port-based VLAN support
- IGMP snooping v1/v2, IGMP filtering / throttling, IGMP query up to 256 group
- Supports IPv4/IPv6, RMON, MIB II, port mirroring, event syslog, DNS, NTP/SNTP, HTTPS, SSH/SSL, TFTP
- MODBUS TCP for SCADA system integration
- Port Configuration
 - Status, statistics, mirroring, rate limiting, event syslog
- Event Handling
 - Event notification by Email: Cold/Warm Start, Power Failure, Authentication, SNMP trap and Fault Alarm Relay Output
- Software Upgrade via TFTP and HTTP
- Configuration Backup – USB Port

1.3 Product Hardware Features

- System Interface and Performance
 - All RJ-45 ports support Auto MDI Function
 - Embedded 8*10/100Tx (PSE 30W/Port) RJ45 Ports, and 2*Gigabit Combo Ports (with 2*10/100/1000Tx RJ45, and 2*100/1000 SFP Slots)
 - Store-and-forward switching architecture
 - 8K MAC address table
 - Power line EFT protection: 2,000VDC; Ethernet ESD protection: 6,000VDC
- Power Input
 - DC 48~55V redundant with a 6-pin removal terminal block
 - One user programmable alarm relay contact
- Operating Temperature
 - Standard operating temperature models: -10°C to 70°C
 - Extended operating temperature models: -40°C to 75°C
- Case/Installation
 - IP-30 protection metal housing
 - DIN-Rail and wall mount design

1.4 Package Contents

- 1– LMP-1002C-SFP series: 10-port industrial gigabit PoE+ managed Ethernet switch, with 8*10/100Tx (PSE 30W/Port) and 2*Gigabit Combo Ports, (w/2*10/100/1000Tx RJ45 and 2*100/1000 SFP Slots)
- 1-Product CD
- 2-Wall mounting brackets and screws
- 1-RJ45 to DB9 Serial Console cable
- 1-DC cable –18 AWG & DC jack 5.5x2.1mm

1.5 Safety Precaution

Attention: If the DC voltage is supplied by an external circuit, please use a protection device on the power supply input. The industrial Ethernet switch's hardware specs, ports, cabling information, and wiring installation will be described within this user manual.

2. Hardware Description

2.1 Physical Dimensions

Figure 2.1, below, shows the physical dimensions of Antaira's LMP-1002C-SFP series: 10-port industrial gigabit PoE+ managed Ethernet switches, with 8*10/100Tx (PSE 30W/Port) and 2*Gigabit Combo Ports, (w/2*10/100/1000Tx RJ45 and 2*100/1000 SFP slots).

(W x D x H) is **54mm x 99mm x 142mm**




Figure2.1

LMP-1002C-SFP Series Physical Dimensions

2.2 Front Panel

The front panel of the LMP-1002C-SFP series industrial gigabit PoE+ managed Ethernet switch is shown below in *Figure 2.2*.




Figure2.2 - The Front Panel of LMP-1002C-SFP Series

2.3 Top View

Figure 2.3, below, shows the top panel of the LMP-1002C-SFP series switch that is equipped with one 6-pin removal terminal block connector for dual DC power inputs 48~55VDC.






Figure2.3

Top Panel View of LMP-1002C-SFP Series

2.4 LED Indicators

There are LED light indicators located on the front panel of the industrial Ethernet switch that display the power status and network status. Each LED indicator has a different color and has its own specific meaning, see below in *Table 2.1*.

LED	Color	Description	
P1	Green	On	Power input 1 is active
		Off	Power input 1 is inactive
P2	Green	On	Power input 2 is active
		Off	Power input 2 is inactive
Fault	Red	On	Power input 1 or 2 is inactive
		Off	Power input 1 and 2 are both functional, or no power, inputs/ports link is active/port alarm is disabled
Owner	Green	On	ERPS Owner Mode (Ring Master) is ready
		Off	ERPS Owner Mode is not active
Ring	Green	On	Ring Network is active
		Off	Ring Network is not active
LAN Port 1 ~ 8 (Left LED)	 Green	On	Connected to network, 10/100/1000Mbps
		Flashing	Networking is active
		Off	Not connected to network
LAN Port 1~ 8 (Right LED) PoE Indicators	 Green	On	The port is supplying power to the powered-device
		Off	No powered-device attached or power supplying fails

Gigabit Combo Ports LED Indicators



LED	Color	Description	
SFP Port Combo G1~G2 LNK/ACT	Green 1000Mbps	On	Connected to network
		Flashing	Networking is active
	Amber 100Mbps	Off	Not connected to network
LAN Port Combo G1 ~G2 (Upper LED)	 Green	On	Connected to network, 1000Mbps
		Flashing	Networking is active
		Off	Not connected to network
LAN Port Combo G1 ~G2 (Lower LED)	 Green	On	Connected to network, 10/100Mbps
		Flashing	Networking is active
		Off	Not connected to network

Table 2.1 - LED Indicators for LMP-1002C-SFP Series

2.5 Reset Button

There is a Reset button located on the front panel of the industrial Ethernet switch that helps users to reboot, restore default, or save running configurations by pressing the button for different

seconds. Please refer to *Table 2.2* for the timing and function.

Seconds	Function
1	Save running configuration to USB
4-6	Reboot the switch
7 or more	Restore factory default

Table 2.2 – Reset Button Functions

2.6 Ethernet Ports

■ RJ-45 Ports

RJ-45 Ports (Auto MDI/MDIX): The RJ-45 ports are auto-sensing for 10Base-T, 100Base-TX, or 1000Base-T connections. Auto MDI means that the switch can connect to another switch or workstation without changing the straight-through or crossover cabling. See the figures below for straight-through and crossover cabling schematics.

■ RJ-45 Pin Assignments

Pin Number	Assignment
1	Rx+
2	Rx-
3	Tx+
6	Tx-

Table 2.3 - RJ45 Pin Assignments

Note: The “+” and “-” signs represent the polarity of the wires that make up each wire pair.

All ports on this industrial Ethernet switch support automatic MDI operations. Users can use straight-through cables (see figure below) for all network connections to PCs, servers, and other switches or hubs. With straight-through cabling, pins 1, 2, 3, and 6 are at one end of the cable and are connected straight through to pins 1, 2, 3 and 6 at the other end of the cable. The table below (*Table 2.3*) shows the 10BASE-T/100BASE-TX/1000BASE-T MDI port pin outs.

Pin MDI-X	Signal Name	MDI Signal Name
1	Receive Data plus (RD+)	Transmit Data plus (TD+)
2	Receive Data minus (RD-)	Transmit Data minus (TD-)
3	Transmit Data plus (TD+)	Receive Data plus (RD+)
6	Transmit Data minus (TD-)	Receive Data minus (RD-)

Table 2.4 - Ethernet Signal Pin

The following figures show the cabling schematics for straight-through and crossover.




Figure 2.4
Straight-Through Cable Schematic




Figure 2.5
Crossover Cable Schematic

2.7 Cabling

Use the four twisted-pair, category 5e, or the above cabling for the RJ-45 port connections. The cable between the switch and the link partner (switch, hub, workstation, etc.) must be less than 100 meters (328 ft.) in length.

2.7.1 Gigabit Combo Port - Copper/SFP (Mini-GBIC)

Antaira Technologies' LMP-1002C-SFP series has two auto-detected Gigabit combo ports (2*10/100/1000Tx RJ45 and 2*100/1000 SFP slots for fiber connection) shown in *Figure 2.6*.

- The Gigabit copper (10/100/1000T) ports should use category 5e or the above UTP/STP cable for the connection up to 1000Mbps. The small form-factor pluggable (SFP) is a compact optical transceiver used in optical communications for both telecommunication and data communications.
- The SFP slots support dual rate mode, which can switch the connection speed between 100 and 1000Mbps. They are used for connecting to the network segment with a single or multi-mode fiber. Users must first choose the appropriate SFP transceiver to plug into the slots, and then choose the proper multi-mode or single-mode fiber according to the transceiver being used. When fiber optic is used, it transmits at a speed up to 1000 Mbps and it can prevent noise interference from the system.




Figure 2.6 – Gigabit Combo Ports

****Note:**

The Gigabit combo ports (SFP/Copper) cannot be working at the same time. The SFP port has a higher priority than the copper port. When inserting a 100M or 1000M SFP transceiver (which has connected to the remote device via fiber cable) into the SFP port, the connection of the accompanying copper port link will be down.

The small form-factor pluggable (SFP) is a compact optical transceiver used in optical communications for both telecommunication and data communication applications. To connect the transceiver and LC cable, please follow the steps below:

First, insert the SFP transceiver module into the SFP slot as shown below in *Figure 2.7*. Notice that the triangle mark is at the bottom of the SFP slot. *Figure 2.8* shows that the SFP transceiver module has been inserted.




Figure 2.7 - Transceiver to the SFP Module



Figure 2.8 - Transceiver Inserted

Second, insert the fiber cable of the LC connector into the transceiver as shown in *Figure 2.9*.




Figure 2.9 - LC Connector to the Transceiver

To remove the LC connector from the transceiver, please follow the steps shown below:

1. Press the upper side of the LC connector from the transceiver and pull it out to release as shown below in *Figure 2.10*.





Figure 2.10 - Remove LC Connector

2. Push down the metal clasp and pull the transceiver out by the plastic part as shown below in *Figure 2.11*.



*Figure 2.11
Pull Out from the SFP Module*

2.8 Wiring the Power Inputs

Please follow the steps below when inserting the power wire.

1. Insert the positive and negative wires into the PWR1 (V1+, V1-) and PWR2 (V2+, V2-) contacts on the terminal block connector as shown below in *Figure 2.12*.




Figure 2.12 - Power Terminal Block

2. Tighten the wire-clamp screws to prevent the wires from loosening, as shown below in *Figure 2.13*.




Figure 2.13 - Power Terminal Block

-
- Note**
- Only use copper conductors, 60/75°C, tighten to 5lbs.
 - The wire gauge for the terminal block should range between 18~20 AWG.
-

2.9 Wiring the Fault Alarm Contact

The fault alarm contact is in the middle of the terminal block connector as the picture shows below in *Figure 2.14*. By inserting the wires, it will detect the fault status including power failure or port link failure (managed industrial switch only) and form a normally open circuit. An application example for the fault alarm contact is shown below in *Figure 2.14*.




Figure 2.14 - Wiring the Fault Alarm Contact

-
- Note**
- The wire gauge for the terminal block should range between 12 ~ 24AWG
-

3. Mounting Installation

3.1 DIN-Rail Mounting

The DIN-Rail is pre-installed on the industrial Ethernet switch from the factory. If the DIN-Rail is not on the industrial Ethernet switch, please see Figure 3.1 to learn how to install the DIN-Rail on the switch.




Figure 3.1

The Rear Side of the Switch and DIN-Rail Bracket

Follow the steps below to learn how to hang the industrial Ethernet switch.

1. Use the screws to install the DIN-Rail bracket on the rear side of the industrial Ethernet switch.
2. To remove the DIN-Rail bracket, do the opposite from step 1.
3. After the DIN-Rail bracket is installed on the rear side of the switch, insert the top of the DIN-Rail on to the track as shown below in *Figure 3.2*.
4. Lightly pull down the bracket on to the rail as shown below in *Figure 3.3*.
5. Check if the bracket is mounted tightly on the rail.
6. To remove the industrial Ethernet switch from the rail, do the opposite from the above steps.




Figure 3.2

Insert the Switch on the DIN-Rail



Figure 3.3

Stable the Switch on DIN-Rail

3.2 Wall Mounting

Follow the steps below to mount the industrial Ethernet switch using the wall mounting bracket as shown below in *Figure 3.4*.

1. Remove the DIN-Rail bracket from the industrial Ethernet switch by loosening the screws.
2. Place the wall mounting brackets on the top and bottom of the industrial Ethernet switch.
3. Use the screws to screw the wall mounting bracket on the industrial Ethernet switch.
4. Use the hook holes at the corners of the wall mounting bracket to hang the industrial Ethernet switch on the wall.
5. To remove the wall mount bracket, do the opposite from the steps above.




Figure 3.4

Remove DIN-Rail Bracket from the Switch

Below, in *Figure 3.5* are the dimensions of the wall mounting bracket.




Figure 3.5

Wall Mounting Bracket Dimensions

4. Hardware Installation

4.1 Installation Steps

This section will explain how to install Antaira's LMP-1002C-SFP series: 10-port industrial gigabit PoE+ managed Ethernet switches with 8*10/100Tx (PSE: 30W/Port) and 2*Gigabit Combo Ports (with 2*10/100/1000Tx RJ45, and 2*100/1000 SFP slots).

Installation Steps

1. Unpack the industrial Ethernet switch from the original packing box.
2. Check if the DIN-Rail bracket is screwed on the industrial Ethernet switch.
 - If the DIN-Rail is not screwed on the industrial Ethernet switch, please refer to the **DIN-Rail Mounting** section for DIN-Rail installation.
 - If you want to wall mount the industrial Ethernet switch, please refer to the **Wall Mounting** section for wall mounting installation.
3. To hang the industrial Ethernet switch on a DIN-Rail or wall, please refer to the **Mounting Installation** section.
4. Power on the industrial Ethernet switch and then the power LED light will turn on.
 - If you need help on how to wire power, please refer to the **Wiring the Power Inputs** section.
 - Please refer to the **LED Indicators** section for LED light indication.
5. Prepare the twisted-pair, straight-through category 5 cable for Ethernet connection.
6. Insert one side of the RJ-45 cable into switch's Ethernet port and on the other side into the networking device's Ethernet port, e.g. switch PC or server. The Ethernet port's (RJ-45) LED on the industrial Ethernet switch will turn on when the cable is connected to the networking device.
 - Please refer to the **LED Indicators** section for LED light indication.
7. When all connections are set and the LED lights all show normal, the installation is complete.

5. Web Management

5.1 Web Console Configuration

This section introduces the configuration by web browser.

5.1.1 About Web-Based Management

All of Antaira's industrial managed switches are embedded with HTML web console interfaces that have a flash memory on the CPU board. It is a "user-friendly" design with advanced management features that allow users to manage the switch from anywhere on the network through any Internet browser, such as Internet Explorer (version 9.0 or above is recommended), Firefox, Chrome and many others.

Preparing for Web Console Configuration

Antaira's industrial managed switches come with a factory default value as below:

- Default IP Address: **192.168.1.254**
- Default User Name: **admin**
- Default Password: **admin**

System Login

1. Launch any Internet browser
2. Type in factory default IP address: `http://192.168.1.254` of the switch. Press "**Enter**".




Figure 5.1 - Web Console "Login"

3. The login screen appears.
4. Key in the default username: **admin** and password **admin**.
5. Click “Login” button, then the main (status) page of the Web Console will appear as below *Figure 5.2*. The online image of the switch will display the real-time ports connection status.




Figure 5.2 - Web Console Main (Status) Page

5.2 Basic Setting

5.2.1 System Information

Below, *Figure 5.3*, shows the switch system setting information.




Figure 5.3 – Switch Settings (Status) Page


Terms	Value Description
System Name	Factory Default: Switch *Users can assign any name label to identify this managed node. By convention, a domain name is a text string drawn from the alphabet (A-Z, a-z), digits (0-9), minus sign (-). No space characters are permitted as part of a name. The first character must be an alpha character. And the first or last character must not be a minus sign. The allowed string length is 0 to 255.
System Description	Factory Default: 6-port Managed PoE Ethernet Switch * Users can assign any new name label to describe this PoE Managed Switch.
System Location	Factory Default: blank *Users can use this field to insert The physical location of this switch (e.g., telephone closet, 3rd floor). The maximum allowed string length is 0 to 255, and the allowed content is the ASCII characters from 32 to 126.
System Contact	Factory Default: blank *Users can insert this field with the administrator of this switch together with information on how to contact this person. The maximum allowed string length is 0 to 255, and the allowed content is the ASCII characters from 32 to 126.
	Click the “Apply” button to save changes.

Figure 5.4 – Switch Settings Description

5.2.2 Admin & Password

Below, describes how to configure the system user name and password for the web console login.




Figure 5.5 – Administrative Account

Terms	Value Description
New Password	Users can assign a New Password, and the maximum allow string length is 0 to 31 characters.
Confirmation	Re-type the new password.
<input type="button" value="Apply"/>	Click the "Apply" to save changes.

Figure 5.6 – Admin & Password Description

5.2.3 IP Setting

Configure the managed switch's IP setting information.

IP Setting

IP CONFIGURATION

DHCP Client:

IP Address:

Subnet Mask:

Gateway:

DNS:

Figure 5.7 – IP Setting Information

Terms	Value Description
DHCP Client	Enable the DHCP client by checking this box. If DHCP fails and the configured IP address is zero, DHCP will retry. If DHCP fails and the configured IP address is non-zero, DHCP will stop and the configured IP settings will be used. The DHCP client will announce the configured System Name as hostname to provide DNS lookup.
IP Address	The unit default IP is 192.168.1.254. Assign the IP address that the network is using. If DHCP client function is enabling, user does not require assigning the IP address. The network DHCP server will assign the IP address for the switch and it will be display in this column.


Subnet Mask	Assign the subnet mask of the IP address. If DHCP client function is enabling, user does not require to assign the subnet mask
Gateway	Assign the network gateway for the switch. If DHCP client function is enabling, user does not require to assign the Gateway.
DNS	Assign the DNS IP address
	Click the "Apply" button to save changes.

Figure 5.8 – IP Setting Information Description

5.2.4 IPv6 Neighbor Cache

The following information provides the current IPv6 neighbors and their states.

IPv6 Neighbor Cache

IPv6 NEIGHBOR CACHE

IPv6 Address	Link Layer(MAC) Address	State
fe80::7941:e3ea:d701:a7cd	c4:6e:1f:03:1e:5a	REACHABLE

Figure 5.9 – IPv6 Neighbor Cache Status

5.2.5 IPv6 Settings

IPv6 Address

IPv6 ENABLE

IPv6 Enable:

IPv6 CONFIGURATION

IPv6 Address	IPv6 Length Prefix	
<input type="text"/>	<input type="text"/>	<input type="button" value="Delete"/>
<input type="button" value="Add"/>		



Figure 5.10 – IPv6 Settings

Terms	Value Description
IPv6 Enable/Disable	Check or uncheck the box to enable or disable IPv6 settings
IPv6 Address	The unit default IPv6 address is depended on MAC address. Assign the IPv6 address that the network is using. Users can add more than one IPv6 addresses.
IPv6 Length Prefix	The prefix length of this IPv6 address
<input type="button" value="Apply"/>	Click the “Apply” to save changes.

Figure 5.11 – IPv6 Terms and Value Description

5.2.6 System Time

Figure 5.12 – System Time Settings

Terms	Value Description
Local Time	Users can define the switch’s local time, or click “Sync with browser” button to have local time setup automatically.
Select Your Time Zone	Users can use dropdown box to setup the switch location time zone
Enable NTP Client	Enable or disable NTP function to get the time from the SNTP server.
Time Server	Users can define the Time Server info
<input type="button" value="Apply"/>	Click the “Apply” button to save changes.

Figure 5.13 – System Time Settings Description

5.3 Port Management

5.3.1 Port Status

The following information provides the current port status.

Status

PORT

No.	Link	Speed	Duplex	Rx Byte	Tx Byte	PoE
1	Down	10	half	0	0	NoSupply
2	Up	100	full	31913127	640601	NoSupply
3	Down	10	half	0	0	NoSupply
4	Down	10	half	28784	1596	NoSupply
5	Down	100	full	0	0	-
6	Down	100	full	0	0	-

Figure 5.14 – Port Status Interface

5.3.2 Port Configuration

Users can assign or insert a “value/label” for each port under each “Port Name” box; enable or disable each port function; state the speed/duplex of each port; and enable or disable the flow control of the port.

Port Configuration

PORT

No.	Link	Port name:	Status	Speed/Duplex	Flow control
1	Down	<input type="text"/>	Enable ▼	Auto ▼	<input type="checkbox"/>
2	Up	<input type="text"/>	Enable ▼	Auto ▼	<input type="checkbox"/>
3	Down	<input type="text"/>	Enable ▼	Auto ▼	<input type="checkbox"/>
4	Down	<input type="text"/>	Enable ▼	Auto ▼	<input type="checkbox"/>
5	Down	<input type="text"/>	Enable ▼		<input type="checkbox"/>
6	Down	<input type="text"/>	Enable ▼		<input type="checkbox"/>

Figure 5.15 – Port Configuration Interface



Terms	Value Description
Port No.	It shows each port status: Up for link active, and Down for link inactive.
Port Name	Users can create or insert a value or label for each port's identification
Status	Enable or disable a port
Speed/Duplex	Users can set the bandwidth of each port as Auto-negotiation, 100 full,100 half,10 full,10 half mode.
Flow Control	Support symmetric and asymmetric mode to avoid packet loss when congestion occurred.
	Click the "Apply" button to save changes.
	Click to undo any changes made locally and revert to previously saved values.

Figure 5.16 – Port Configuration Description

5.4 PoE (Power-over-Ethernet)

LMP-1002C-SFP series is one of Antaira's industrial PoE+ gigabit managed switches that has four built-in IEEE802.3at compliant ports, and each PoE port can support PoE output power up to a maximum of 30W per port. It is also backward compatible with IEEE 802.af to support any standard PoE powered devices (PD).

5.4.1 PoE Configuration

POE Configuration

PoE PORT

No.	Status	Mode	Consumption
1	No PD Detected	Enable ▼	0.00W
2	No PD Detected	Enable ▼	0.00W
3	No PD Detected	Enable ▼	0.00W
4	No PD Detected	Enable ▼	0.00W




Figure 5.17 – PoE Port Configuration Interface


Terms	Value Description
Port No.	PoE Port Number
Status	Any PoE port will automatically detect any PD (Powered Device) is connected and display the situation.
Mode	Users can use the dropdown box to enable or disable any PoE port function
Consumption	Set the PoE power output limit value. The maximum value must less than 30.0W
	Click the "Apply" button to save changes.

Figure 5.18 – PoE Port Configuration Description

5.4.2 Ping Alarm

The PoE ping alarm function is using the ping command to turn on or off any PoE power output port. Users can insert any particular powered device’s IP address and set the interval time for a power recycle, timing the particular PoE port.

Power over Ethernet

PoE KEEPALIVE

PD	IP Address	Cycle Time(s)
1	<input style="width: 90%;" type="text"/>	<input style="width: 90%;" type="text"/>
2	<input style="width: 90%;" type="text"/>	<input style="width: 90%;" type="text"/>
3	<input style="width: 90%;" type="text"/>	<input style="width: 90%;" type="text"/>
4	<input style="width: 90%;" type="text"/>	<input style="width: 90%;" type="text"/>




Figure 5.19 – PoE Ping Alarm Interface

5.4.3 PoE Schedule

For energy saving or power recycle powered devices, the PoE managed switch's PoE schedule interface allows users to appoint any date and time to enable or disable PoE functions for each PoE port.

The screenshot displays the 'Power over Ethernet' configuration page, specifically the 'PoE SCHEDULE' section. At the top, there are four tabs labeled 'Port1', 'Port2', 'Port3', and 'Port4', with 'Port1' currently selected. Below the tabs, the interface is organized into four rows, one for each day of the week: Monday, Tuesday, Wednesday, and Thursday. Each row begins with a label like 'Monday Enable' followed by a small square checkbox. To the right of each 'Enable' label are two dropdown menus: 'Start time(hour):' and 'End time(hour):'. In the visible portion of the interface, the 'Start time' dropdown for Monday is set to '0', and the 'End time' dropdown is also set to '0'. The 'Start time(hour):' dropdown for Tuesday is also visible and set to '0'. The 'Wednesday Enable' and 'Thursday Enable' labels are visible, but their corresponding dropdowns are not fully shown in the image.

Figure 5.20 – PoE Schedule Interface

5.5 ERPS

In any industrial automation application, designing redundant ring network paths to protect networks from unexpected failovers is extremely important in mission-critical networks because they need to provide uninterrupted services. In practice, several loop protection methods are implemented to ensure that network functions normally without loops and recovers as soon as possible when a point of failure occurs. The most popular ones are RSTP (802.1w) and MSTP (802.1s). For industrial applications, the ERPS (G.8032) is highly recommended since they can achieve faster recovery time than any STP protocol.

Due to different manufacturers who provide their own proprietary redundant ring protocol, and users facing inconvenient situations with compatibility issues when they are planning to design or upgrade their ring network for future proof, Antaira is proud to introduce and implement Ethernet Ring Protection Switching (ERPS) protocol as a standard ring solution for network redundancy with all new industrial managed Ethernet switches. In order to provide users with the flexibility and compatibility when there are any existing switches that contains the standard ERPS protocol.

Ethernet Ring Protection Switching (ERPS), defined in ITU-T G8032, implements a protection switching mechanism for Ethernet traffic in a ring topology. By performing the ERPS function, potential loops in a network can be avoided by blocking traffic to flow to the ring protection link (RPL) to protect the entire Ethernet ring.

In a network with ring topology that runs ERPS, only one switch is assigned as an “owner” that is responsible for blocking traffic in RPL so as to avoid loops. The switch adjacent to the RPL owner is called the RPL “neighbor” node that is responsible for blocking its end of the RPL under normal condition. Other participating switches adjacent to the RPL owner or neighbor in a ring are members or RPL next-neighbor nodes to this topology and normally forward receive traffic. ERPS, like STP, provides a loop-free network by using polling packets to detect faults. When a fault occurs, ERPS heals itself by sending traffic over a protected reverse path less than 50ms and recover quickly to forward traffic. Because of this fault detection mechanism, the network broadcast storm problem could be avoided as well.

5.5.1 ERPS Status

Below, *Figure 5.21*, shows the network redundancy ring status with the Ethernet Ring Protection Switch (ERPS) protocol.



Figure 5.21 – Redundant Ring Network – ERPS Status

5.5.2 ERPS Configuration

Below, *Figure 5.22*, shows the ERPS configuration interface.




Figure 5.22 – ERPS Configuration Interface


Terms	Value Description
Protocol	“Enable” or “Disable” ERPS protocol
Ring Port 0	ERPS ring port 0, it could be map to real switch port 1 – port 6. Do not set the same as Ring port 1.
Ring Port 1	ERPS ring port 1, it could be map to real switch port 1 – port 6. Do not set the same as Ring port 0.
Role	Set the ERPS role as Owner, Neighbor or None. [Owner] In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port. [Neighbor] In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port. [None] Besides Owner and Neighbor node, the rest of nodes are defined as None node. All node roles have the ability to block the port if the link attach to the port is failed and disconnected.
Ring ID	ERPS ring ID, ranges from 1 to 239. Ring ID distinguishes different Ring topology.
Channel	ERPS Channel ID, ranges from 1 to 4094. It's a channel to send PDUs of ERPS.
Revertive	Set to Revertive (yes) or Non-revertive (no). The revertive mode works only under the scenario A at the RPL Owner node. [Revertive] While the revertive mode is set, the RPL link will be blocked in 5 minutes after recovery form link failure situation. Otherwise, it will remain unchanged of the blocking state. That is, the failed link port will block permanently until the next event happen. [Non-Revertive] The failed ring link the port attached to it will remain blocked even the situation is eliminated.
	Click the “Apply” button to save changes.

Figure 5.23 – ERPS Configuration Terms & Description

5.5.3 Before Configuring ERPS

Before configuring ERPS, the rapid spanning tree protocol (RSTP), or multiple spanning tree protocol is required to be disabled, due to only one protocol is exclusive running within a switch. Below are the steps to disable RSTP, or MSTP.

- Step 1:** Login the switch with a web browser.
- Step 2:** Open the “RSTP Configuration” page under the “Spanning Tree” manual shown below in *Figure 5.24*.




Figure 5.24 – Spanning Tree Manual

- Step 3:** When the RSTP/CIST Configuration page shows up, set “Mode” to “Disable” as shown in *Figure 5.25*.




Figure 5.25 – RSTP/CIST Configuration Interface

Step 4: Press the 'Apply' button in the lower right corner as below *Figure 5.26*.

RSTP/CIST Configuration

RSTP/CIST

Mode: RSTP
 Root Priority: MSTP
 Root Hello Time: 2
 Root Forward Delay: 15
 Root Maximum Age: 20

RSTP/CIST PORT

No.	Path Cost(0:Auto,1-200000000)	Priority	Admin P2P	Auto Edge	Admin Non STP
1	0	128	True	Auto	False
2	0	128	True	Auto	False
3	0	128	True	Auto	False
4	0	128	True	Auto	False
5	0	128	True	Auto	False
6	0	128	True	Auto	False

Apply

Figure 5.26 – RSTP/CIST Configuration Interface

Ethernet Ring Protection Switch (ERPS) is an Ethernet ring protection protocol which is used to prevent forming the loop in LAN, thus, the Broadcast Storm problem could be avoided. The loop avoidance mechanism ensures the traffic flows on all but the RPL ring link. In order to achieve the loop-avoidance mechanism, ITU-T G.8032 defines three roles in ERPS, which are “RPL Owner Node”, “RPL Neighbor Node”, and “None Node”.

Below are two scenarios describing how to configure the ERPS in Antaira’s Industrial managed Ethernet switches. Users can reference it to configure the managed switch as RPL-configured architecture as shown in *Figure 5.27* or the non-configured architecture shown in *Figure 5.31*.

5.5.3.1 Scenario A – RPL Configured Architecture

Under scenario A, there are three major roles required to configure within the ERPS configuration.




Figure 5.27 – RPL-Configured Architecture

Caution: Before enabling any ERPS protocols on any of the Ring Nodes, please DO NOT connect all switches to form a loop (ring) network yet. There should have at least one ring port leave unplugged until all nodes in the topology are ready.


[RPL Owner Node]

Only one RPL Owner Node can be set in a ring network. In order to set up the RPL Owner Node, one must choose a switch and enable the “Protocol” under the ERPS Configuration interface. Follow the steps below and use *Figure 5.28* as an example:

- Step 1:** Choose a specific port from the dropdown menu, next to “ring port 0”, and set it as the “Owner” node by clicking the dropdown menu next to “Role”. At this point, “Port 1” has been chosen as an example.
- Step 2:** Choose a specific port from the dropdown menu, next to “ring port 1”, then set it as “None” from the dropdown menu next to “Role” (which locates below “ring port 1”). At this point, “Port 2” has been chosen as an example.

Note: The port number of “Ring Port 0” and “Ring Port 1” cannot be duplicated.

After the configurations, press the “Apply” button on the right bottom corner to save the setting.



The screenshot displays the 'ERPS Configuration' window. At the top, it says 'ERPS CONFIGURE'. Below this, there are several configuration fields:

Protocol:	Enable
Ring Port 0:	Port1
Role:	Owner
Ring Port 1:	Port2
Role:	None
Ring ID:	1
APS Channel:	1000
Revertive:	Yes

An 'Apply' button is located in the bottom right corner of the configuration area.


Figure 5.28 – RPL Owner Node Setup Example

Please be aware, when the revertive mode is set to “Yes”, the ring will recover the same way as explained in *Figure 5.27*, after the ring state form goes from ABNORMAL to NORMAL in 5 minutes. Otherwise, the blocked port will remain blocked permanently unless users reconfigure it.

[RPL Neighbor Node]

Users should choose a second managed switch that is adjacent to the first managed switch and set it up as the RPL neighbor node. For configuration, users should login to the second managed switch's ERPS configuration interface and choose a specific port number under "Ring Port 0" and set it as the "None" node by clicking the dropdown box of "Role"; then, set another specific port number under "Ring Port 1" as the "Neighbor" node as shown below in *Figure 5.29*. So the link between neighbor port and owner port forms the ring protection link (RPL). After the configurations, press the "Apply" button on the bottom right corner to save the settings.

Note: The port number of "Ring Port 0" and "Ring Port 1" cannot be duplicated.



The screenshot displays the "ERPS Configuration" interface. At the top, the title "ERPS Configuration" is followed by a sub-section "ERPS CONFIGURE". Below this, several configuration fields are listed, each with a label and a corresponding input field:

Protocol:	Enable ▼
Ring Port 0:	Port1 ▼
Role:	None ▼
Ring Port 1:	Port2 ▼
Role:	Neighbor ▼
Ring ID:	1
APS Channel:	1000
Revertive:	Yes ▼

An "Apply" button is located in the bottom right corner of the configuration area.

Figure 5.29 – RPL Neighbor Node Setup Example

[None Node]

Then users should setup the rest of the managed switches' "Role" of both "Ring Port 0 and 1" as "None Node" as shown above in *Figure 5.27*. Please be sure no duplicate port number has been chosen within a managed switch's ERPS ring setting, the incorrect configurations may lead to unexpected errors.

The screenshot displays the 'ERPS Configuration' window. At the top, it says 'ERPS CONFIGURE'. Below this, there are several configuration fields:

Protocol:	Disable
Ring Port 0:	Port1
Role:	None
Ring Port 1:	Port2
Role:	None
Ring ID:	1
APS Channel:	1000
Revertive:	Yes

An 'Apply' button is located at the bottom right of the configuration area.

Figure 5.30 – RPL None Node Setup Example

5.5.3.2 Scenario B – Non-Configured Architecture

In some situations, users can choose not to configure the RPL owner and neighbor node. The ERPS can still work well under the mechanism by blocking one of the ring ports in the ERPS ring topology.




Figure 5.31 – Non-Configured Architecture

Caution: Before enabling any ERPS protocols on any of the Ring Nodes, please DO NOT connect all switches to form a loop (ring) network yet. There should have at least one ring port leave unplugged until all nodes in the topology are ready.

Shown above in Figure 5.31, the ERPS is blocked at one of the ring node ports. The blocked port is chosen by an election mechanism that is decided by the MAC address. Due to the MAC address is unique; the ERPS will just choose the biggest MAC as the blocking node.

However, the user is still required to enable the RRPS protocol, and assign a dedicated port number for each uplink port under “Ring Port 0 and 1” but there is no requirement to setting the role. Figure 5.32, below, shows the configurations as a reference.

After the configurations, press the “Apply” button on the bottom right corner to save the settings.

ERPS Configuration

ERPS CONFIGURE

Protocol:	Disable ▼
Ring Port 0:	Port1 ▼
Role:	None ▼
Ring Port 1:	Port2 ▼
Role:	None ▼
Ring ID:	1
APS Channel:	1000
Revertive:	Yes ▼

Figure 5.32 – Non-Configured Architecture Setup

5.6 Spanning Tree

The Spanning Tree Protocol (STP), defined in the IEEE Standard 802.1d, can be created within a mesh network of connected layer-2 switches.

The Rapid Spanning Tree Protocol (RSTP), defined in the IEEE 802.1w. RSTP is an enhanced solution of STP. It shares most of its basic operation characteristics, and essentially creates a cascading effect away from the root bridge where each designated bridge proposes to its neighbors to determine if it can make a rapid transition.

Another extension of RSTP is the Multiple Spanning Tree protocol (MSTP), defined in the IEEE802.1s. It allows different VLANs to travel along separate instances of spanning tree. Unlike STP and RSTP, MSTP eliminates the needs for having different STP for each VLAN. Therefore, in a large networking environment that employs many VLANs, MSTP can be more useful than legacy STP.

5.6.1 RSTP Status

Figure 5.33 shows the RSTP algorithm results.




Figure 5.33 – RSTP Information Interface

5.6.2 RSTP Configuration

Users can enable/disable the RSTP function, and set the parameters for each port.

RSTP/CIST Configuration

RSTP/CIST

Mode:

Root Priority:

Root Hello Time:

Root Forward Delay:

Root Maximum Age:

RSTP/CIST PORT

No.	Path Cost(0:Auto,1-200000000)	Priority	Admin P2P	Auto Edge	Admin Non STP
1	0	128	True	Auto	False
2	0	128	True	Auto	False
3	0	128	True	Auto	False
4	0	128	True	Auto	False
5	0	128	True	Auto	False
6	0	128	True	Auto	False

Figure 5.34 – RSTP Configuration Interface

Terms	Value Description
Mode	Users can select RSTP or MSTP function to be enabled or disabled before configuring the related parameters.
Root Priority (0~61440)	A value used to identify the root bridge. The bridge with the lowest value has the highest priority and is selected as the root. If any change of the value, the switch is required to be reboot. The value must be multiple of 4096 according to the protocol standard rule.
Root Hello Time (1~10)	Enter a value between 1 through 10 for the time to control the switch to send out the BPDU packet for RSTP current status checking.
Root Forward Delay (4~30)	Enter a value between 4 through 30 as the number of seconds for a port to wait before changing from its RSTP learning and listening states to the forwarding state.
Root Maximum Age (6~40)	Enter a value between 6 through 40 as the number of seconds a bridge waits without receiving STP configuration messages before attempting a


	reconfiguration.
Path Cost (0~200000000)	Enter a value from 1 through 200000000 to define the path cost for the other switch from this transmitting switch at the specified port. When path cost insert in 0, the switches will be setup as automatic data transmitting.
Priority (0~240)	Enter a number 0 through 240 to decide which port should be blocked by priority in LAN. The value of priority must be the multiple of 16
Admin P2P	Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port concerned can only be connected to exactly one other switch (i.e. It is served by a point-to-point LAN segment), or it can be connected to two or more switches (i.e. It is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. True means P2P enabling. False means P2P disabling.
Auto Edge	The port is directly connected to end stations, and it cannot create bridging loop in the network. To configure the port as an edge port, set the port to " True ".
Admin Non STP	The port includes the STP mathematic calculation. True is not including STP mathematic calculation. False is including the STP mathematic calculation.
	Click the "Apply" button to save changes.

Figure 5.35 – RSTP Configuration Terms & Value Description

MSTP (Multiple Spanning Tree Protocol)

It is defined in IEEE 802.1s; it can map a group of VLAN's into a single Multiple Spanning Tree instance (MSTI). In fact, the Spanning Tree Protocol is applied separately for a set of VLAN's instead of the whole network. Different root switches and different STP parameters can be individually configured for each MSTI. So, one link can be active for one MSTI and the other link active for the second MSTI. This enables some degree of load-balancing and generally two MSTI's are used in the network for easier implementation.

5.6.3 MSTI Status

Users can display the MSTI root status and port status by selecting the instance ID number from 1 to 15 by clicking on the dropdown box from the “MSTI Status” interface.

MSTI Status

Instance ID: 1 ▼

Root Status

Root Address: _____
 Root Priority: _____
 Root Port: _____
 Root Path Cost: _____

MSTI Port Status

No.	Role	Path State	Port Cost	Port Priority
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				

Figure 5.36 – MSTI Status Interface

5.6.4 MSTI Configuration

Users can display the MSTI root status and port status by selecting the “Instance ID” number from 1 to 15 by clicking on the dropdown box from the “MSTI Status” interface.

MSTI Configuration

MSTI Configuration

Name: FC:CB:0D:AD:DC:14
 Revision(0-65535): 0

MSTI Instance

Instance.	Vlan group	Priority
1		32768 ▼
2		32768 ▼
3		32768 ▼
4		32768 ▼
5		32768 ▼
6		32768 ▼
7		32768 ▼
8		32768 ▼
9		32768 ▼
10		32768 ▼
11		32768 ▼
12		32768 ▼
13		32768 ▼
14		32768 ▼
15		32768 ▼

Figure 5.37 – MSTI Configuration Interface

Terms	Value Description
MSTI Configuration	
Name	Users can insert the unique MAC address of the bridge switch.
Revision	Users can insert the value from 0~65535
MSTI Instance	
Instance No. & VLAN Group	There are 1~15 instance number, user can insert which VLAN Group info into the belonging Instance number
Priority (0~61440)	<p>A value used to identify the root bridge.</p> <p>The bridge with the lowest value has the highest priority and is selected as the root.</p> <p>The switch is required to reboot when there's any value change.</p> <p>The value must be multiple of 4096 according to the protocol standard rule.</p>
Apply	Click the "Apply" button to save changes.

Figure 5.38 – MSTI Configuration –Terms & Value Description

Figure 5.39 – MSTI Port Configuration Interface


Terms	Value Description
Instance Tabs	Users can select Instance Tab #1~#15 to configure each MSTI port "Cost" & "Priority" value.
Cost	Users can define the path cost value from 1 through 200000000 to the other bridge from this transmitting bridge at the specified port.
Priority	Users can decide which port should be blocked by priority in LAN by select the value from 0 to 240 from the dropdown box.
	Click the "Apply" button to save changes.

Figure 5.40 – MSTI Port Configuration Terms & Value Description

5.7 IGMP Snooping

The Internet Group Management Protocol (IGMP) is a communications protocol used to manage the membership of Internet Protocol multicast groups. IGMP is used by IP hosts and adjacent multicast routers to establish multicast group memberships.

When IGMP snooping is enabled in a switch, it analyzes all the IGMP packets between hosts connected to the switch and multicast routers in the network. When a switch receives an IGMP report for a given multicast group from a host, the switch adds the host's port number to the multicast list for that group. When the switch hears an IGMP leave, it removes the host's port from the table entry.

IGMP snooping can reduce multicast traffic from streaming and other bandwidth intensive IP applications more effectively. A switch using IGMP snooping will only forward multicast traffic to the hosts in that traffic. This reduction of multicast traffic reduces the packet processing at the switch (at the cost of needing additional memory to handle the multicast tables) and also decreases the workload at the end hosts since their network cards (or operating system) will not receive and filter all the multicast traffic generated in the network.

IGMP has 3 versions, IGMP v1, v2, and v3, and support query group up to 256 groups.

5.7.1 IGMP Settings

Figure 5.41 – IGMP Snooping Settings Interface

Terms	Value Description
IGMP Protocol	Check the box to enable or disable IGMP Snooping
Querier	Switch will be IGMP querier or not. There should have the existing one and only one IGMP querier in an IGMP application – up to 256 Groups
Query Interval	The frequency at which the querier sends query messages
Query Max Response Time	The maximum response time advertised.
Apply	Click the “Apply” button to save changes.

Figure 5.42 – IGMP Snooping Settings Terms & Value Description

5.7.2 IGMP Snooping Status Table

Multicast filtering is the system by which end stations only receive multicast traffic if they register to join specific multicast groups. With multicast filtering, network devices only forward multicast traffic to the ports that are connected to registered end stations.

Group	Port
239.0.0.1	1,3
239.0.0.2	1
239.0.0.3	1

Figure 5.43 – IGMP Snooping Status Table

5.8 802.1Q VLAN

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain, which allows users to isolate network traffic. Only the members of the VLAN will receive traffic from the same members on that VLAN. Basically, creating a VLAN from a switch is logically equivalent of reconnecting a group of network devices to another Layer 2 switch. However, all the network devices are still physically plugged into the same switch.

All Antaira's industrial managed switches support 802.1Q VLAN. Tagged-based VLAN is an IEEE 802.1Q specification standard, and it is possible to create a VLAN across devices from different switch vendors. IEEE 802.1Q VLAN uses a technique to insert a "tag" into the Ethernet frames. Tag contains a VLAN Identifier (VID) that indicates the VLAN numbers.

The managed switches also provide users with a defined management VLAN, so that users can connect an Antaira switch to other "commercial" switches that have existed and set a non VLAN 1 management VLAN.

5.8.1 802.1Q VLAN Settings

All of Antaira's industrial managed switches' have a default VLAN 1 setting set to "Untag" for each port, so the users can login to the VLAN setting interface to create a VLAN Group name and choose "Tag" or "Untag" for each port.

ID	name	1	2	3	4	5	6	
1		Untag	Untag	Untag	Untag	Untag	Untag	Delete
100		none	Untag	none	Tag	none	none	Delete

+ Add

Apply

Figure 5.44 – 802.1Q VLAN Settings Interface


Terms	Value Description
Management VLAN ID	Set the VLAN ID of management VLAN. Users have to configure other settings done, and configure this field finally.
802.1Q VLAN ID	The ID of this VLAN. VLANs that have the same ID will consider being the same group.
802.1Q VLAN Name	The name of this VLAN. The same VLAN in the different switches can have different name.
	Click the “Apply” button to save changes.

Figure 5.45 – 802.1Q VLAN Settings Terms

5.8.2 802.1Q VLAN Port Settings

802.1Q VLAN Port

802.1Q VLAN PVID

Port	PVID
1	1
2	1
3	1
4	1
5	1
6	1

802.1Q VLAN FILTER

Port	Filter
1	None ▼
2	None ▼
3	None ▼
4	None ▼
5	None ▼
6	None ▼




Figure 5.46 – 802.1Q VLAN Port Settings Interface


Terms	Value Description
PVID	When a frame comes into the port, it will be tagged with the PVID if the frame is without VLAN tag.
Filter	An incoming frame will be dropped or kept forwarding according to the filter. <ul style="list-style-type: none">• None: All frames can keep forwarding.• Tagged: Only the frames with 802.1Q tag can keep forwarding, untagged frames will be dropped.• Untagged: Only the frames without 802.1Q tag can keep forwarding, tagged frames will be dropped.
	Click the "Apply" button to save changes.

Figure 5.47 – 802.1Q VLAN Settings Terms & Value Description

5.9 QoS (Traffic Prioritization)

Network traffic is always unpredictable and the only basic assurance that can be offered is the best effort traffic delivery. To overcome this challenge, Quality of Service (QoS) is applied throughout the network. This ensures that network traffic is prioritized according to specified criteria and receives preferential treatments.

Traffic Prioritization includes three modes: port base, 802.1p/COS, and TOS/DSCP. By traffic prioritization function, users can classify the traffic into four classes for differential network application. All of Antaira's industrial managed switches support four priority queues.

5.9.1 QoS Classification

Figure 5.48 – QoS Classification Interface

Terms	Value Description
Queue Scheduling	<p>Users can set it as “Weighted” or “Strict”</p> <p>Weighted Mode: An 8, 4, 2, 1 weighting is applied to each round robin priority queue.</p> <p>Strict Mode: It gives egress queues with higher priority to be transmitted first before lower priority queues are serviced.</p>
Trust Mode	<p>Users can select the trust mode with either DSCP or Cos. When select DSCP, only trusted DSCP (Differentiated Services Code Point) values are mapped to a specific QoS class and drop precedence level (DPL). Frames with untrusted DSCP values are treated as non-IP frames.</p> <p>CoS: (Class Of Service) is well known as 802.1p. It describes that the output priority of a packet is determined by user priority field in 802.1Q VLAN tag. The priority value is supported 0to7COS value map to 4 priority</p> <p>Queues: Highest, SecHigh, SecLow, and Lowest.</p>
Default Cost	<p>Users can set each port's priority queue from 0 to 7 by clicking from dropdown box; of which 0 is the Highest, and</p>

	7 is the Lowest
<input type="button" value="Apply"/>	Click the "Apply" button to save changes.

Figure 5.49 – QoS Classification Terms & Value Description

5.9.2 CoS Mapping

CoS Mapping

CoS Mapping

Cos	Priority
0	Normal
1	Low
2	Low
3	Normal
4	Medium
5	Medium
6	High
7	High

Figure 5.50 – CoS Mapping Interface

Terms	Value Description
Cos Value (0~7)	Users can assign each port a CoS value from 0 to 7. According to the IEEE 802.1p, user can define each CoS value in 4 priority queues: from Low to Normal, Medium, and High.
<input type="button" value="Apply"/>	Click the "Apply" button to save changes.

Figure 5.51 – QoS Mapping Terms & Value Description

5.9.3 ToS Mapping

ToS is an acronym for Type of Service. It is implemented as the IPv4 ToS priority control. It is fully decoded to determine the priority from the 6-bit ToS field in the IP header. The most significant 6 bits of the ToS field are fully decoded into 64 possibilities, and the singular code that results is compared against the corresponding bit in the IPv4 ToS priority control bit (0-63).




Figure 5.52 – ToS Mapping Interface

Terms	Value Description
ToS	Users can assign each ToS value with 4 priority queues form 0 (Low) to 1 (Normal), 2 (Medium), and 3 (High).
<input type="button" value="Apply"/>	Click the “Apply” button to save changes.

Figure 5.53 – ToS Mapping Terms & Value Description

5.10 Port Trunk

Port Trunk, also called “Link Aggregation”, is a method of combining multiple network connections in parallel. It is to increase throughput beyond what a single connection could sustain. For example, if the application requires a 5-Gigabit link, and each port supports only 1-Gigabit link, the “Port Trunk” allows users to link 5 of 1-Gigabit ports to obtain a 5-Gigabit trunk feature. All Antaira’s industrial managed switches support 2 types of Port Trunk. One is LACP (dynamic) and the other is Static.

- LACP mode is more flexible, and it can change modes, either trunk or single port.
- Dynamic Port Trunk also provides a redundancy function, in case one of the links fail. If one of the trunk members has failed, it will still work well in LACP mode, but it will link down if using static mode. Static mode is still necessary, because some devices only support static trunk.

5.10.1 Trunk Status

The below graph is the Port Trunk Status.

Trunk Status		
AGGREGATION		
Group	Type	Port
1	lacp	1,2
2	-	-
3	-	-
4	lacp	3,5,6
5	-	-
6	-	-
7	-	-
8	-	-

Figure 5.54 – Port Trunk Status

The below table describes the term and value description of “Port Trunk”.

Terms	Value Description
Aggregation	Show the status of Port Trunk. List all Trunks and show their type and members.

Figure 5.55 – Port Trunk Terms and Value Description

5.10.2 Trunk Configuration

The below graph is the “Port Trunk” configuration interface.

The screenshot shows the 'Trunk Configuration' interface. It is divided into two main sections: 'AGGREGATION GROUP TYPE' and 'AGGREGATION GROUP MEMBER'. Each section contains a table with dropdown menus for configuration.

AGGREGATION GROUP TYPE	
Group ID	Trunk Type
Trunk1	LACP
Trunk2	LACP
Trunk3	LACP
Trunk4	LACP
Trunk5	LACP
Trunk6	LACP
Trunk7	LACP
Trunk8	LACP

AGGREGATION GROUP MEMBER	
PORT NO.	Group ID
Port1	Trunk 1
Port2	Trunk 1
Port3	None
Port4	None
Port5	None
Port6	None

Figure 5.56 – Port Trunk Configuration Interface

The below table describes the field of the terms and value descriptions of “Port Trunk”.

Terms	Value Description
Aggregation Group Type	Type “LACP” for dynamic trunking, and type “Static” for static trunking.
Aggregation Group Member	Map ports to Trunk1 ~ Trunk 8.

Figure 5.57 – Port Trunk Terms and Value Description

5.11 Port Mirroring

Enable or disable mirroring feature. When enabled, a copy of matched frames will be mirrored to the destination port specified in the port mirroring interface.

The screenshot shows a configuration window for port mirroring. At the top, it says 'Port Mirroring'. Below that, in red text, is 'PORT MIRRORING'. The main area contains several controls: a checkbox for 'Port Mirror Mode', two dropdown menus for 'Go To Interface' and 'Monitor Direction' (both showing 'None'), and a list of ports from Port1 to Port6, each with a checkbox. An 'Apply' button is at the bottom right.

Figure 5.58 – Port Mirroring Configuration Interface

Terms	Value Description
Port Mirror Mode	Enable Port Mirroring function by check the box
Go To Interface	Users can use the dropdown box to choose the destination port as “Port to mirror on” feature
Monitor Direction	Users can select the monitor direction from the dropdown box by “Tx”, “Rx”, or “Tx/Rx”.
Source Port	Users can decide any particular port as the source port(s) will require port mirroring.
Apply	Click the “Apply” button to save changes.

Figure 5.59 – Port Mirroring Terms & Value Description

5.12 SNMP

Simple Network Management Protocol (SNMP) is the protocol developed to manage nodes (servers, workstations, routers, switches and hubs etc.) on an IP network. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth. Network management systems learn of problems by receiving traps or change notices from network devices implementing SNMP.





5.12.1 SNMP Agent

SNMP Agent

SNMP GENERAL

SNMP Version:	v1 , v2c , v3 ▼
Read-Only Community	public
Read and Write Community	private


SNMP v3

Admin Auth level:	Auth-only ▼
Admin Auth Type:	SHA ▼
Auth Passphrase 
Admin Data Encrypt Type:	AES ▼
Encrypt Passphrase 
User Auth level:	Auth-only ▼
User Auth Type:	SHA ▼
Auth Passphrase 
User Data Encrypt Type:	AES ▼
Encrypt Passphrase 

Apply

Figure 5.60 – SNMP Agent Setup Interface

SNMP General

Terms	Value Description
SNMP Version	All Antaira Managed Switches support SNMP v1, v2c, and v3 server. Users can enable all SNMP server v1, v2c and v3, or enable only v1 and v2c, or enable only enable v3. Default SNMP server is enabled, set version to "None" to disable it.
Read-Only Community	Using "Read-Only Community" on the SNMP MIB walk utility can only read information.
Read and Write Community	Using "Read and write Community" on the SNMP MIB walk utility not only can read information, but can write/edit part of information.
	Click "Apply" button to save changes.

SNMP V3

There are 2 accounts when using SNMP v3 authentication. These 2 accounts are "admin" and "user". In this section, it introduces the authentication settings and encryption information.


Terms	Value Description
Admin Auth level	"Auth-only" means only do authentication but not encrypt data. "Both" means both do authentication and encrypt data. "None" means not do authentication and not encrypt data.
Admin Auth Type	The method used to encrypt the passphrase
Auth Passphrase	"Auth Passphrase" is a string used to authenticate (Admin).
Admin Data Encrypt Type	The method used to encrypt the data.
Encrypt Passphrase	"Encrypt Passphrase" is a string used to encrypt data (Admin).
User Auth level	"Auth-only" means only do authentication but not encrypt data. "Both" means both do authentication and encrypt data. "None" means not do authentication and not encrypt data.
User Auth Type	The method used to encrypt the passphrase
Auth Passphrase	"Auth Passphrase" is a string used to authenticate (User).
User Data Encrypt Type	The method used to encrypt the data.
Encrypt Passphrase	"Encrypt Passphrase" is a string used to encrypt data (User).
	Click "Apply" button to save changes.

Figure 5.61 – SNMP Agent Interface Terms & Value Description

5.12.2 SNMP Trap Setting

Trap Setting

SNMP

Trap Mode:	<input type="text" value="None"/>
Inform Retry:	<input type="text" value="10"/>
Inform Timeout:	<input type="text" value="30"/>
Trap Destination IP:	<input type="text"/>
Community:	<input type="text" value="public"/>

Figure 5.62 – SNMP Trap Setting

Terms	Value Description
Trap Mode	SNMP Trap is disabled (set to “None”) by default. Users can set it to “Trap v1”, “Trap v2c”, or “Inform (v2c)”. If users set it to “Trap”, the trap message will only send once, but if set the mode to “Inform”, the trap message will send “Inform Retry” times.
Inform Retry	The trap message will be sent “Inform Retry” times. This field works only when “Trap Mode” is set to “Inform”.
Inform Timeout	The trap message will be sent after “Inform Timeout” expired. This field works only when “Trap Mode” is set to “Inform”.
Trap Destination IP	The Destination IP that trap message will be sent to.
<input type="button" value="Apply"/>	Click “Apply” button to save changes.

Figure 5.63 – SNMP Trap Settings Terms & Value Description

5.13 DHCP Server / Rely

DHCP Client & Server

Dynamic Host Configuration Protocol (DHCP) is a standardized network protocol. It is used on Internet Protocol (IP) networks for dynamically distributing network configuration parameters. For example, devices can request IP addresses for interfaces from a DHCP server. Using DHCP can also reduce the need for a network administrator or a user to configure these settings manually. The protocol operates based on the client-server model. When DHCP Clients connect to a network, they will send a broadcast query to request necessary information from a DHCP server. DHCP Servers manage a pool of IP address and network configuration information. If they get queries from DHCP Clients, they will automatically distribute IP address and network parameters to them.

DHCP Relay Agent

DHCP Relay Agents help DHCP Clients forwarding request to DHCP Servers. With DHCP Relay Agents, DHCP Servers and Clients will not know each other. A Relay Agent can connect to more than 1 DHCP Server, so that DHCP Clients will have more resources.

DHCP Relay Option 82

Users can also use the information of DHCP Relay Option 82 to distribute IP address. Antaira's industrial managed switches provides "Cisco-like" Option 82 format. It contains Circuit ID and Remote ID. The packets format of Circuit ID and Remote ID are shown as below Figure 5.64 and Figure 5.66; and the detail of packet fields are in Figure 5.65 and Figure 5.67. The IP addresses will get more controllable with DHCP Relay Option 82 function.




Figure 5.64 – DHCP Relay Option 82 Circuit ID

Field	Description
VLAN	The management VLAN ID. Always VLAN 1.
Module	The stack number. Always 0 here.
Port	It is the incoming port number from DHCP Client, and the port number is started by 1.

Figure 5.65 – DHCP Relay Option 82 Circuit ID Details




Figure 5.66 – DHCP Relay Option 82 remote ID

Field	Description
MAC Address	The MAC address of the Relay Agent. The MAC address is all hex format and without “:” or “-”, for example, “7CCB0AC49B2D”.

Figure 5.67 – DHCP Relay Option 82 Remote ID Details

5.13.1 DHCP Client

The below figure is the IP Setting of DHCP Client.

IP Setting

IP CONFIGURATION

DHCP Client:

IP Address:

Subnet Mask:

Gateway:

DNS:

Figure 5.68 – DHCP Client IP Configuration

The below table describes the field of the DHCP Client terms and value descriptions.

Terms	Value Description
DHCP Client	“Enable” or “Disable” DHCP Client.
IP Address	Static IP address setting. Assign the IP address that the network is using.
Subnet Mask	Assign the subnet mask of the IP address.
Gateway	The IP address that connects the LAN to the Internet.
DNS	The IP address of DNS.

Figure 5.69 – DHCP Client Terms and Value Description

5.13.2 DHCP Server

The below figure is the DHCP Server web interface.

Figure 5.70 – DHCP Server Configuration

The below table describes the field of the DHCP Server terms and value description.

Terms	Value Description
Server Status	DHCP Server Status, It shows “Down” when “Disable”, and it shows “Up” when “Enable”.
Enable	“Enable” or “Disable” DHCP Server.
Included Start Address	The start address of the pool that DHCP Server managed.

Included End Address	The end address of the pool that DHCP Server managed.
Default Gateway	The IP address that connects the LAN to the Internet.
Name Server	The IP address of DNS.
Lease Time	A controllable time period that DHCP server will reclaim IP addresses.

Figure 5.71 – DHCP Server Terms and Value Description

5.13.3 DHCP Server Binding

The below figure is the web interface for DHCP Server Binding

Figure 5.72 – DHCP Server Binding Interface

Terms	Value Description
ID	“Enable” or “Disable” DHCP Client.
Binding Mac	The MAC address of the device that wishes binding.
Binding IP	The IP address that will assign to the device with the Binding MAC address.

Figure 5.73 – DHCP Server Binding Terms and Value Description

5.13.4 DHCP Relay

DHCP Relay

DHCP RELAY

Enable:	<input type="checkbox"/>
Relay option82:	<input type="checkbox"/>
Relay to server1:	<input type="text"/>
Relay to server2:	<input type="text"/>
Relay to server3:	<input type="text"/>
Relay to server4:	<input type="text"/>

DHCP RELAY UNTRUST

No.	Relay Untrust
1	Disable
2	Disable
3	Disable
4	Disable
5	Disable
6	Disable

Figure 5.74 – DHCP RELAY Interface

Apply

DHCP RELAY

Terms	Value Description
Enable	“Enable” or “Disable” DHCP Relay Agent
Relay Option 82	“Enable” or “Disable” DHCP Relay Option 82
Relay to server1	The IP address of the first DHCP Server that Relay Agent connect to
Relay to server2	The IP address of the second DHCP Server that Relay Agent connect to
Relay to server3	The IP address of the third DHCP Server that Relay Agent connect to
Relay to server4	The IP address of the fourth DHCP Server that Relay Agent connect to

Figure 5.75 – DHCP RELAY – Terms & Value Description

DHCP RELAY UNTRUST

Terms	Value Description
Relay Untrust	Per-port “Enable” or “Disable” Relay Untrust. DHCP frames can pass that port when it set to “Enable” only.

Figure 5.76 – DHCP RELAY – Terms & Value Description

5.14 802.1X

802.1X is an IEEE Standard for Port-based Network Access Control. It provides an authentication mechanism to devices that wish to attach to a LAN or WLAN. This port-based network access control protocol contains 3 parts, supplicant, authenticator, and authentication server. With 802.1X authentication, we can link a username with an IP address, MAC address, and port. This provides greater visibility into the network. 802.1X also provides more security because it only allows traffic transmitting on authenticated ports or MAC addresses. Although the IEEE standard defined it as a “Port-based” control, to provide more robust service, Antaira implements all managed switches with 802.1X to a “MAC-based” access control.

RADIUS

RADIUS is used in the authentication process. Database of authorized users is maintained on a RADIUS server. There is an authenticator, our switch enabling 802.1X, to forward the authentication requests between authentication (RADIUS) server and client. Allowing or denying the requests decides if the client can connect to a LAN/WAN or not.

5.14.1 802.1X Settings

The below figure is the 802.1X configuration interface.

802.1X

802.1X

802.1X Enable:

Server Type:

802.1X PORT

No.	Enable Port	Re-Auth	Re-Auth Period(Sec.)
1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
9	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600

Figure 5.77 – 802.1X Configuration Interface

The below table describes 802.1X Terms and Value Description.

802.1X

Terms	Value Description
802.1X Enable	Check the checkbox to enable “802.1X” protocol.
Server Type	“Local” for authenticating with local server setting on the “Local Database” page.

802.1X Port

Terms	Value Description
No.	The number of ports, from 1 to N, N depends on models.
Enable Port	Check the checkbox(es) to enable authentication before connecting to a LAN or WAN.
Re-Auth	“Re-Auth” means re-authenticate, it is enabled by default. Check the checkbox(es) to enable re-authentication after “Re-Auth Period” seconds.
Re-Auth Period(Sec.)	“Re-Auth Period” default value is 3600 seconds (60 minutes). Switch will ask the client for re-authentication every “Re-Auth Period” seconds.
No.	The number of ports, from 1 to N, N depends on models.

Figure 5.78 – 802.1X – Terms & Value Description

5.14.2 Local Database

The below figure is the Local Database web interface.

Local Database

LOCAL DATABASE

User Name	Password	Confirm Password
<input type="button" value="Delete"/>		
<input type="button" value="Add"/>		

Figure 5.79 – Local Database Web Interface

The below table describes Local Database Terms and Value Description.

Terms	Value Description
User Name	The user name use to authenticate in 802.1X when server set to "Local".
Password	The password use to authenticate in 802.1X when server set to "Local".
Confirm Password	Fill in the password again.

Figure 5.80 – Local Database – Terms & Value Description

5.14.3 RADIUS Server

The below figure is the RADIUS Server setting interface.

Radius Server

RADIUS SERVER



1st Server IP	<input type="text"/>
1st Server Port	<input type="text" value="1812"/>
1st Server Shared Key	<input type="text"/> 
2nd Server IP	<input type="text"/>
2nd Server Port	<input type="text" value="1812"/>
2nd Server Shared Key	<input type="text"/> 

Figure 5.81 – RADIUS Server Setting Interface

The below table describes RADIUS Server Terms and Value Description.


Terms	Value Description
Server IP	IP Address of RADIUS server
Server Port	"Server Port" default value is 1812. Switch will communicate with RADIUS server via this port.
Server Shared Key	Shared key is used to authenticate authenticator (switch) and authentication (RADIUS) server. Click "  " icon to show the shared key.

Figure 5.82 – RADIUS Server – Terms & Value Description


5.15 UPnP

Universal Plug and Play (UPnP) is a set of networking protocols that were promoted by the UPnP Forum. UPnP Protocol permits networked devices to discover each other's presence on the network and seamlessly establish functional network services for data sharing, communications, and entertainment.

The concept of UPnP is an extension of plug-and-play, a technology for dynamically attaching devices directly to a computer. But UPnP is not directly related to the earlier plug-and-play technology any more. UPnP devices are "plug-and-play" in that when connected to a network they automatically establish working configurations with other devices.

5.15.1 UPnP

Below, *Figure 5.83*, is the UPnP web interface.



The screenshot shows a web interface for UPnP configuration. At the top, the title "UPnP" is displayed. Below it, the sub-section "UPnP" is shown. The configuration area contains two settings: "UPnP Enable:" with an unchecked checkbox, and "UPnP interval:" with a text input field containing the value "1800". An "Apply" button is located at the bottom right of the configuration area.

Figure 5.83 – UPnP Configuration Interface

The below table describes UPnP Terms and Value Description.

Terms	Value Description
UPnP Enable	"Enable" or "Disable" UPnP protocol
UPnP Interval	UPnP Interval is the setting of Advertisement interval. It controls the time of sending advertisement.

Figure 5.84 – UPnP Terms and Value Description

5.16 Modbus TCP

Modbus is a serial communications protocol that is used with industrial automation equipment, such as programmable logic controllers (PLCs), sensors, and meters. It is a common, simple, and robust method of connecting industrial devices.

MODBUS TCP is a variant of the MODBUS family, vendor-neutral communication protocol commonly used for the integration of a SCADA system; of which, it covers the use of MODBUS messaging in an 'intranet' or 'internet' environment using the TCP/IP protocols.

According to the standard, Modbus encapsulates the message with an Ethernet TCP/IP wrapper. Antaira's industrial Managed Ethernet switches support Modbus TCP/IP protocol to allow users to integrate it into those industrial control systems for real-time monitoring in a SCADA system.

5.16.1 Enable Modbus TCP

Below, *Figure 5.85*, is the ModbusTCP web interface.

The screenshot shows a web interface titled 'Modbus'. Below the title is a red-bordered box containing the text 'Modbus Tcp Enable:' followed by an unchecked checkbox. To the right of the box is an 'Apply' button.

Figure 5.85 – Modbus TCP Web Interface

The below table describes Modbus Terms and Value Description.

Terms	Value Description
Modbus TCP Enable	Check the checkbox to enable Modbus TCP.

Figure 5.86 – Modbus TCP – Terms & Value Description

5.16.2 MODBUS Data Map and Information

The data map addresses for Antaira's switches are shown in the table for **Function Code 6**.

Address Offset	Data Type	Interpretation	Description
System Information			
0x0000 to 0x0005	1 word	HEX	Port 1 to 6 Status 0x0000 : Link down 0x0001 : Enable 0x0002 : Disable Port 1 to 6 Status Configuration 0x0001 : Enable 0x0002 : Disable

The data map addresses for Antaira's switches are shown in the following table starting from MODBUS for Function Code 4. For example, the address offset 0x0000 (hex) equals MODBUS address 30001, and the address offset 0x0015 (hex) equals MODBUS address 30022. Note that all the information read from Antaira switches are in hex mode. To interpret the information, refer to the ASCII table for the translation (e.g. 0x41 = 'A', 0x6E = 'n').

Address Offset	Data Type	Interpretation	Description
System Information			
0x0000	1 word	HEX	Vendor ID = 0x0000
0x0001	1 word		Unit ID (Ethernet = 1)
0x0002	1 word	HEX	Product Code = 0x0000
0x0010	20 words	ASCII	Vendor Name = "Antaira" Word 0 Hi byte = 'A' Word 0 Lo byte = 'n' Word 1 Hi byte = 't' Word 1 Lo byte = 'a' Word 2 Hi byte = 'i' Word 2 Lo byte = 'r' Word 3 Hi byte = 'a' Word 3 Lo byte = '\0'
0x0030	20 words	ASCII	Product Name = "LMP-0602" Word 0 Hi byte = 'L' Word 0 Lo byte = 'M' Word 1 Hi byte = 'P' Word 1 Lo byte = '-' Word 2 Hi byte = '0' Word 2 Lo byte = '6' Word 3 Hi byte = '0' Word 3 Lo byte = '2' Word 4 Hi byte = '\0' Word 4 Lo byte = '\0'
0x0050	1 word		Product Serial Number
0x0051	2 words	HEX	Firmware Version For example : Word 0 = 0 x 0203 Word 1 = 0 x 0300 Firmware Version was 2.3.3
0x0053	2 words	HEX	Firmware Release Date

			For example : Word 0 = 0 x 2319 Word 1 = 0 x 1501 Firmware was released on 2015-01-23 at 19:00
0x0055	3 words	HEX	Ethernet MAC Address Ex : MAC = 7C:CB:0D:AD:DC:14 Word 0 Hi byte = 0 x 7C Word 0 Lo byte = 0 x CB Word 1 Hi byte = 0 x 0D Word 1 Lo byte = 0 x AD Word 2 Hi byte = 0 x DC Word 2 Lo byte = 0 x 14
0x0058	1 word	HEX	Power 1 0x0000 : Off 0x0001 : On
0x0059	1 word	HEX	Power 2 0x0000 : Off 0x0001 : On
0x005A	1 word	HEX	Fault LED Status 0x0000 : Boot error 0x0001 : Normal 0x0002 : Fault
0x0082	1 word	HEX	DO1 0x0001 : Normal 0x0002 : Fault
Port Information			
0x1000 to 0x1005	1 word	HEX	Port 1 to 6 Status 0x0000 : Link down 0x0001 : Link up 0x0002 : Disable 0xFFFF : No port
0x1100 to 0x1105	1 word	HEX	Port 1 to 6 Speed 0x0000 : 10M-Half 0x0001 : 10M-Full 0x0002 : 100M-Half

			0x0003 : 100M-Full 0xFFFF : No port
0x1200 to 0x1205	1 word	HEX	Port 1 to 6 Flow Ctrl 0x0000 : Off 0x0001 : On 0xFFFF : No port
0x1300 to 0x1305	1 word	HEX	Port 1 to 6 MDI/MDIX 0x0000: MDI 0x0001: MDIX 0xFFFF: No port
0x1400 to 0x1413 (Port 1) 0x1414 to 0x1427 (Port 2)	20 words	ASCII	Port 1 to 6 Name Port Name = "100FDX,RJ45." Word 0 Hi byte = '1' Word 0 Lo byte = '0' Word 1 Hi byte = '0' Word 1 Lo byte = 'F' ... Word 5 Hi byte = '5' Word 5 Lo byte = '.'
Packets Information			
0x2000 to 0x200B	2 words	HEX	Port 1 to 6 Tx Packets Ex : Port1 Tx Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2080 to 0x208B	2 words	HEX	Port 1 to 6 Tx Bytes Ex : Port1 Tx Bytes Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2100 to 0x210B	2 words	HEX	Port 1 to 6 Rx Packets Ex : Port1

			Rx Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2180 to 0x218B	2 words	HEX	Port 1 to 6 Rx Bytes Ex : Port1 Rx Bytes Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2200 to 0x220B	2 words	HEX	Port 1 to 6 Tx Error Packets Ex : Port 1 Tx Error Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2300 to 0x230B	2 words	HEX	Port 1 to 6 Rx Error Packets Ex : Port1 Rx Error Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
Redundancy Information			
0x3000	1 word	HEX	Redundancy Protocol 0x0000 : None 0x0001 : RSTP 0x0002 : MSTP 0x0003 : ERPS
0x3100	1 word	HEX	RSTP Root 0xFFFF : None 0x0001 : Root

			0x0002 : Not root
0x3200 to 0x3205	1 word	HEX	RSTP Port 1 to 6 Status 0xFFFF : Spanning tree not enable 0x0000 : Disable 0x0001 : Not spanning tree port 0x0002 : Link down 0x0003 : Blocked 0x0004 : Learning 0x0005 : Forwarding
0x3300	1 word	HEX	ERPS Port0 Role 0xFFFF : ERPS not enable 0x0000 : Normal 0x0001 : Neighbor 0x0002 : RPL Owner
0x3301	1 word	HEX	ERPS Port1 Role 0xFFFF : ERPS not enable 0x0000 : Normal 0x0001 : Neighbor 0x0002 : RPL Owner
0x3302	1 word	HEX	ERPS Port0 Status 0x0000 : Disable 0x0001 : ERPS not enable 0x0002 : Link down 0x0003 : Forwarding 0x0004 : Learning 0x0005 : Blocking
0x3303	1 word	HEX	ERPS Port1 Status 0x0000 : Disable 0x0001 : ERPS not enable 0x0002 : Link down 0x0003 : Forwarding 0x0004 : Learning 0x0005 : Blocking
0x3304	1 word	HEX	ERPS Port0 Port Ex : ERPS Port0 is Port1 Word 0 = 0 x0001

0x3305	1 word	HEX	ERPS Port1 Port Ex : ERPS Port1 is Port2 Word 0 = 0 x0002
--------	--------	-----	--

Figure 5.87 – Antaira Switches – Modbus Data Map & Information

5.17 System Warning

System warning function is very important for managing a switch. Users can manage the switch by “Syslog”, “System Event Log”, and “Email Server” setup for Advanced Notice in any event type, “Event Type Selection”, and “Fault Alarm” setting. By setting up all these system warning features, users will receive the in advanced warning message through email, whenever any event occurs. It definitely increases the flexibility and capability for the user to monitor the remote site network and device statuses.

5.17.1 Syslog Setting

The SYSLOG is a protocol to transmit event notification messages across networks.




Figure 5.88 – Syslog Setting

Terms	Value Description
SYSLOG Mode	Disable: disable SYSLOG. Local Only: log to local system. Remote Only: log to a remote SYSLOG server. Local And Remote: log to local server and remote SYSLOG server at the same time.
SYSLOG Server IP Address	Insert remote SYSLOG server IP address
Apply	Click the “Apply” button to save changes.

Figure 5.89 – SYSLOG Setting Terms & Value Description

5.17.2 System Event Log

Users can view and display the system event log by clicking the “Apply” button on the right bottom corner of the interface. Then, the system event logs will display within the SYSLOG LIST window. The SYSLOG LIST will contain up to 5 pages of system event log information. Users also can click the “Refresh” button to have the most updated system event logs information to display.




Figure 5.90 – System Event Logs Interface

5.17.3 SMTP Setting

The Simple Mail Transfer Protocol (SMTP) is for e-mail transmission across the Internet.

Figure 5.91 – SMTP Setting Interface

Terms	Value Description
E-mail Alert	Enable/Disable transmission system warning events by e-mail.
SMTP Server Address	Setting up the mail server IP address
Sender E-mail Address	Set up the email account to send the alert.
Mail Subject	The subject of the mail
Authentication	Check the box to enable the Authentication function Username: the authentication username. Password: the authentication password.
Recipient E-mail Address(es)	Users can setup up to 4 recipient E-mail addresses to receive any system warning message.
Apply	Click the “Apply” button to save changes.

Figure 5.92 – SMTP Setting Terms & Value Description

5.17.4 Event Selection

Users can select any event type through the “Event Selection” interface, such as “System Cold Start”, any ports’ “Link Up”, “Link Down”, “Link Up & Link Down” and send the system warning message to either SYSLOG or SMTP, or both at the same time. After the event selection, users can click the “Apply” button to save changes.

Event Selection

EVENT SELECTION

Event	SYSLOG	SMTP
System Cold Start:	<input type="checkbox"/>	<input type="checkbox"/>

EVENT SELECTION PORT

Port No.	SYSLOG	SMTP
1	Disable	Disable
2	Disable	Disable
3	Disable	Disable
4	Disable	Disable
5	Disable	Disable
6	Disable	Disable

Figure 5.93 – Event Selection Setting Interface

5.17.5 Fault Alarm

When any selected fault event has occurred, the fault LED of the switch’s front panel will light up and the electric relay will signal at the same time. Users can check the checkbox of any “Fault Alarm” type, such as power failure, port link down or broken through the “Fault Alarm” setting interface to trigger this function.

Fault Alarm

FAULT ALARM

- Power1 Failure:
- Power2 Failure:
- Port1 Link Down/Broken:
- Port2 Link Down/Broken:
- Port3 Link Down/Broken:
- Port4 Link Down/Broken:
- Port5 Link Down/Broken:
- Port6 Link Down/Broken:

Figure 5.94 – Event Selection Setting Interface

5.18 MAC Table

The MAC address table is the filtering database that supports queries by the forwarding process, as to whether a frame received by a given port with a given destination MAC address is to be forwarded through a given potential transmission port.

5.18.1 MAC Address Table

MAC Address Table

MAC Address Table

VID	Mac	Type	Port
1	00:00:21:ff:ff:ff	learning	2
1	00:20:4a:ea:70:d3	learning	2
1	00:30:ab:26:cb:04	learning	2
1	00:50:7f:47:22:8a	learning	2
1	01:00:5e:00:01:3c	static	2
1	01:00:5e:7f:ff:fa	static	2
1	10:bf:48:5a:b4:0d	learning	2
1	1c:af:f7:7c:5b:f6	learning	2
1	30:85:a9:a7:9d:63	learning	2
1	30:85:a9:a8:05:bb	learning	2
1	44:6d:57:47:27:04	learning	2
1	48:5b:39:d1:1f:06	learning	2
1	54:53:ed:af:5c:bd	learning	2
1	7c:cb:0d:08:01:5e	learning	2
1	e0:3f:49:e7:44:c2	learning	2
1	ec:43:f6:6f:90:fd	learning	2
1	f4:ce:46:c8:01:9f	learning	2

Figure 5.95 – MAC Address Table Interface

5.18.2 MAC Table Configuration

Users can check the checked box of each port and insert the port's VID and MAC address of the device that is connected to that port, then click the "Add" button to continue adding other ports' information. Click the "Apply" button to save all the settings.

MAC Table Configuration

MAC Table Configuration

VID	Mac	1	2	3	4	5	6
<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Figure 5.96 – MAC Table Setting Interface

5.19 Maintenance

Under the maintenance section, users can execute the updated firmware upgrade, system reboot, and reset the system to factory default.

5.19.1 Upgrade

Antaira is continuously developing new functions and features for specific application requirements for the industrial managed switches. Users can download the latest firmware from Antaira's website and store it within their local PC, or server.




Figure 5.97 – Firmware Upgrade Interface

Terms	Value Description
FIRMWARE UPGRADE	Users can click the “Choose File” button to select the latest firmware from the local PC, or Server; then click the “Upgrade” button to have the switch be updated.

Figure 5.98 – Firmware Upgrade Setting Terms & Value Description

5.19.2 Reboot

Users can click the “Apply” button under the “Reboot” interface to reboot the switch.




Figure 5.99 – Switch Reboot Interface

5.19.3 Default

Users can reset the switch to “Factory Default” by clicking the “Apply” button under the default interface.




Figure 5.100 – Reset Factory Default Interface

5.20 Configuration

Under the “Configuration” section, users can save all the settings that have been configured, backed up and stored to a local PC, Server, or a USB storage device through the built-in USB port. Users can use the USB port feature to execute the “Auto Load” function to boot the switch’s configuration that has been saved within the USB storage device, or users can utilize this function to “Auto Load” the configuration to other switches, and those switches would require the same configuration settings.

Users can keep the USB storage device plugged in with the switch to enable the USB “Auto Backup” function to allow the switch’s configuration settings to back up to the USB storage device whenever users makes and save configuration settings.

5.20.1 Save

Users can click the “Save” button under the “SAVE CONFIGURATION” interface, once all the settings had been configured.




Figure 5.101 – Save Setting Interface

5.20.2 Backup & Restore




Figure 5.102 – Backup & Restore Setting Interface

Terms	Value Description
CONFIGURATION MANAGEMENT	
Backup Configuration	By clicking the “Backup” button, it allows users to back up the switch configuration setting to their local PC, or server.
Upload Configuration	Users can click the “Choose File” button to select the saved configuration file from local PC, or server, then click the “Upload” the settings to the switch.
USB Management	
Save Running Config to USB	Click the button of Backup to save running-config file to USB.
Save Startup Config to USB	Click the button of Backup to save startup-config file to USB.
Upload Config from USB	Click the button of Upload to load startup-config from USB.

Figure 5.103 – Backup & Restore Setting Terms & Value Description

5.20.3 Auto Load & Backup



Figure 5.104 – USB Auto Load and Backup Setting Interface

Terms	Value Description
USB Auto Load	Select USB Auto Load (plug USB stick and reboot the switch), it will auto load startup file from USB to Switch. Please make sure the startup file name is “switch- [MAC ADDRESS].cfg”, if the file didn't exist, it will find “switch-config.cfg”. If all of them didn't exist, it does not work.
USB Auto Backup	Select USB Auto Backup, it can auto Backup running-config file from Switch to USB. And the file name is “startup-config”.

Figure 5.105 – USB Auto Load and Backup Setting Terms & Value Description

5.21 Logout

Users can logout of the web console interface by clicking 'logout' from the menu.

6. Command Line Interface Management

6.1 About CLI Management

Besides WEB-based management, LMP-1002C-SFP series also supports CLI management. Users can use console or telnet to management switch by CLI.


CLI Management by RS-232 Serial Console (115200, 8, none, 1, none)

Before configuring by an RS-232 serial console, use an RJ45 to DB9-F cable to connect the switches' RS-232 Console port to the PC's COM port.

Follow the steps below to access the console via RS-232 serial cable.


Step 1:

From the Windows desktop, click on Start -> Programs -> Accessories -> Communications -> Hyper Terminal.




Step 2:

Input a name for the new connection.




Step 3:

Select to use a specific COM port number.



Step 4:

The COM port property settings are as follows: 115200 for “Bits per second”, 8 for “Data bits”, None for Parity, 1 for “Stop bits” and none for “Flow control”.



Step 5:

The Console login screen will appear. Use the keyboard to enter the Username and Password, and then press “**Enter**”.

```
User Access Verification
Username: admin
Password:
SWES> en
SWES# configure terminal
```

CLI Management by Telnet

Users can use “**TELNET**” to configure the switches.


The default value is as below:

- IP Address: **192.168.1.254**
- Subnet Mask: **255.255.255.0**
- Default Gateway: none
- User Name: **admin**
- Password: **admin**

Follow the steps below to access the console via Telnet.

Step 1:

Telnet to the IP address of the switch from the Windows “**Run**” command as below.



Step 2:

The Login screen will appear. Use the keyboard to enter the Username and Password, and then press “**Enter**”

```
User Access Verification
Username: admin
Password:
SWES> en
SWES# configure terminal
```

Commander Groups

Group	Command	Mode
System	hostname [Switch]	configure
	no hostname	configure
	system location [none]	configure
	system contact [none]	configure
	no system location	configure
	no system contact	configure
	show system uptime	configure
	show system mac	configure
	show system version firmware	configure
	show system version loader	configure
	admin username admin	configure
	admin password admin	configure
	IP	boot host dhcp
ip address [ip_addr] [ip_mask]		configure
ip default-gateway [ip_router]		configure
ip name-server [ip_addr_string]		configure
no boot host dhcp		configure
no ip default-gateway		configure
no ip name-server		configure
show boot host dhcp		configure
show ip address		configure
show ip default-gateway		configure
show ip name-server		configure
show ip mode		configure
Time	ntp time update	configure
	ntp client timeserver [ip_addr_string]	configure
	clock set [hh:mm:ss] [day] [month] [year]	configure
	clock timezone [area] [city]	configure
	ntp client sync [minute hour day month year] [NUMBER]	configure
	no ntp client timeserver	configure
	no clock timezone	configure
Time	no ntp client sync [minute hour day month year] [NUMBER]	configure
	show ntp client timeserver	configure

	show clock timezone	configure
	show ntp client sync [minute hour day month year] [NUMBER]	configure
Port	speed [auto 10 100 1000] [full half]	interface
	Duplex [auto full half]	interface
	flowcontrol <receive> [on off desired]	interface
	name [string]	interface
	shutdown	interface
	no speed	interface
	no duplex	interface
	no flowcontrol	interface
	no name	interface
	no shutdown	interface
	show speed	interface
	show duplex	interface
	show flowcontrol	interface
	show name	interface
	show link rx	interface
	show link tx	interface
show link summary	interface	
VLAN	management vlan [vlan_id]	configure
	name [vlan_name]	vlan
	member [member_portlist] [<untag_portlist>]	vlan
	switchport pvid [vlan_id]	interface
	switchport filter [tagged untagged]	interface
	no name	vlan
	no member	vlan
	no switchport pvid	interface
	no switchport filter	interface
	show name	vlan
	show member	vlan
	show switchport pvid	interface
show switchport filter	interface	
ERPS	ethernet ring erps major	configure
	enable	erps
	disable	erps

	rpl [port0 port1] [owner neighbor]	erps
	aps-channel [channel ID]	erps
	revertive	erps
	clear	erps
	port0 interface [interface name]	erps
	port1 interface [interface name]	erps
	fs [port0 port1]	erps
	ms [port0 port1]	erps
	ring-id [erps ring ID]	erps
	timer hold-off [0~1000]	erps
	timer guard [10~2000]	erps
	timer wtr [1~12]	erps
	no rpl [port0 port1]	erps
	no aps-channel	erps
	no revertive	erps
	no port0	erps
	no port1	erps
	no ring-id	erps
	no timer hold-off	erps
	no timer guard	erps
	no timer wtr	erps
	show status	erps
	show brief	erps
	show port status	erps
	show ethernet ring g8032 configuration	erps
PoE	power inline never	interface
	keepalive ip [IP_Address]	interface
	keepalive time [Seconds]	interface
	schedule [monday~sunday] enable	interface
	schedule [monday~sunday] starttime [Hour]	interface
	schedule [monday~sunday] endtime [Hour]	interface
	no power inline never	interface
	no keepalive ip	interface
	no keepalive time	interface
	no schedule [monday~sunday] enable	interface

	no schedule [monday~sunday] starttime	interface
	no schedule [monday~sunday] endtime	interface
	show power inline status	interface
	show keepalive ip	interface
	show keepalive time	interface
	show schedule [monday~sunday] enable	interface
	show schedule [monday~sunday] starttime	interface
	show schedule [monday~sunday] endtime	interface
STP	spanning-tree mode [rstp mst]	configure
	spanning-tree priority [priority_value]	configure
	spanning-tree forward-time [forward time]	configure
	spanning-tree hello-time [hello_time]	configure
	spanning-tree max-age [max_age]	configure
	spanning-tree cost [link_cost_value]	interface
	spanning-tree port-priority [port_priority]	interface
	spanning-tree link-type [point-to-point point-to-multiple]	interface
	spanning-tree auto-edge off	interface
	spanning-tree admin-edge on	interface
	spanning-tree stp disable	interface
	no spanning-tree mode	configure
	no spanning-tree priority	configure
	no spanning-tree forward-time	configure
	no spanning-tree hello-time	configure
	no spanning-tree max-age	configure
	no spanning-tree mst [instance_ID] priority	configure
	no spanning-tree cost	interface
	no spanning-tree port-priority	interface
	no spanning-tree link-type	interface
no spanning-tree auto-edge	interface	
no spanning-tree admin-edge	interface	
no spanning-tree stp	interface	
STP	show spanning-tree mode	configure
	show spanning-tree priority	configure
	show spanning-tree forward-time	configure
	show spanning-tree hello-time	configure

	show spanning-tree max-age	configure
	show spanning-tree cost	interface
	show spanning-tree port-priority	interface
	show spanning-tree link-type	interface
	show spanning-tree auto-edge	interface
	show spanning-tree admin-edge	interface
	show spanning-tree stp	interface
	spanning-tree mst [instance_ID] priority [priority]	configure
	spanning-tree mst name [NAME]	configure
	spanning-tree mst revision [REVISION]	configure
	spanning-tree mst instance [instance_ID] vlan [vlan_grp]	configure
	spanning-tree mst [instance_ID] cost [cost_value]	interface
	spanning-tree mst [instance_ID] port-priority [priority]	interface
	no spanning-tree mst name	configure
	no spanning-tree mst revision	configure
	no spanning-tree mst instance [instance_ID] vlan	configure
	no spanning-tree mst [instance_ID] cost	interface
	no spanning-tree mst [instance_ID] port-priority	interface
	show spanning-tree mst name	configure
	show spanning-tree mst revision	configure
	show spanning-tree mst instance [instance_ID] vlan	configure
	show spanning-tree mst [instance_ID] priority	configure
	show spanning-tree mst [instance_ID] cost	interface
	show spanning-tree mst [instance_ID] port-priority	interface
Event	event smtp power1 enable	configure
	event smtp power2 enable	configure
	event smtp cold-start enable	configure
	event smtp warm-start enable	configure
	event smtp authentication-failure enable	configure
	event smtp erps-change enable	configure
	event smtp interface [INTERFACE_NAME] up	configure
	event smtp interface [INTERFACE_NAME] down	configure
	no event smtp power1	configure
	no event smtp power2	configure
	no event smtp cold-start	configure

no event smtp warm-start	configure
no event smtp authentication-failure	configure
no event smtp erps-change	configure
no event smtp interface [INTERFACE_NAME] up	configure
no event smtp interface [INTERFACE_NAME] down	configure
show event smtp power1	configure
show event smtp power2	configure
show event smtp cold-start	configure
show event smtp warm-start	configure
show event smtp authentication-failure	configure
show event smtp erps-change	configure
show event smtp interface [INTERFACE_NAME] up	configure
show event smtp interface [INTERFACE_NAME] down	configure
event syslog power1 enable	configure
event syslog power2 enable	configure
event syslog cold-start enable	configure
event syslog warm-start enable	configure
event syslog authentication-failure enable	configure
event syslog erps-change enable	configure
event syslog interface [INTERFACE_NAME] up	configure
event syslog interface [INTERFACE_NAME] down	configure
no event syslog power1	configure
no event syslog power2	configure
no event syslog cold-start	configure
no event syslog warm-start	configure
no event syslog authentication-failure	configure
no event syslog erps-change	configure
no event syslog interface [INTERFACE_NAME] up	configure
no event syslog interface [INTERFACE_NAME] down	configure
show event syslog power1	configure
show event syslog power2	configure
show event syslog cold-start	configure
show event syslog warm-start	configure
show event syslog authentication-failure	configure
show event syslog erps-change	configure

	show event syslog interface [INTERFACE_NAME] up	configure
	show event syslog interface [INTERFACE_NAME] down	configure
	event alarm power1 enable	configure
	event alarm power2 enable	configure
	event alarm interface [INTERFACE_NAME] down	configure
	no event alarm power1	configure
	no event alarm power2	configure
	no event alarm interface [INTERFACE_NAME] down	configure
	show event alarm power1	configure
	show event alarm power2	configure
	show event alarm interface [INTERFACE_NAME] down	configure
	event apply	configure
SYSLOG	syslog server [IP_address]	configure
	syslog mode [all remote local usb]	configure
	no syslog server	configure
	no syslog mode	configure
	show syslog server	configure
	show syslog mode	configure
	show syslog log	configure
SMTP	smtp enable	configure
	smtp sender [E-MAIL_ADDR]	configure
	smtp subject [subject_text]	configure
	smtp server address [GMAIL_SMPT_SERVER]	configure
	smtp server port [GMAIL_SMPT_SERVER]	configure
	smtp authentication enable	configure
	smtp authentication username [GMAIL_ACCOUNT]	configure
	smtp authentication password [GMAIL_PASS]	configure
	smtp receive [1 2 3 4] [e-mail_address]	configure
	no smtp enable	configure
	no smtp sender	configure
	no smtp subject	configure
	no smtp server address	configure
	no smtp server port	configure
	no smtp authentication enable	configure
no smtp authentication username	configure	

	no smtp authentication password	configure
	no smtp receive [1 2 3 4]	configure
	show smtp state	configure
	show smtp sender	configure
	show smtp subject	configure
	show smtp server address	configure
	show smtp server port	configure
	show smtp authentication enable	configure
	show smtp authentication username	configure
	show smtp receive [1 2 3 4]	configure
SNMP	snmp server enable [<v1-v2c-only v3-only>]	configure
	snmp server community [ro rw] [community_name]	configure
	snmp server v3 level [admin user] [auth noauth priv]	configure
	snmp server v3 auth [admin user] [md5 sha] [PWD]	configure
	snmp server v3 encryption [admin user] [des aes] [PWD]	configure
	no snmp server enable	configure
	no snmp server community [ro rw]	configure
	no snmp server v3 level [admin user]	configure
	no snmp server v3 auth [admin user]	configure
	no snmp server v3 encryption [admin user]	configure
	show snmp server enable	configure
	show snmp server community [ro rw]	configure
	show snmp server v3 level [admin user]	configure
	show snmp server v3 auth [admin user]	configure
	show snmp server v3 encryption [admin user]	configure
	snmp trap enable	configure
	snmp trap host [DESTINATION_IP]	configure
	snmp trap version [1 2c 3] [traps inform]	configure
	snmp trap community [trap_community_name]	configure
	snmp trap inform retry [retry_time]	configure
	snmp trap inform timeout [retry_interval]	configure
	snmp trap v3 user [user_ID]	configure
	snmp trap v3 level [auth noauth priv]	configure
snmp trap v3 engine-ID [engineID]	configure	
snmp trap v3 auth [md5 sha] [PASSWORD]	configure	

	snmp trap v3 encryption [des aes] [PASSWORD]	configure
SNMP	no snmp trap enable	configure
	no snmp trap host	configure
	no snmp trap version	configure
	no snmp trap community	configure
	no snmp trap inform retry	configure
	no snmp trap inform timeout	configure
	no snmp trap v3 user	configure
	no snmp trap v3 level	configure
	no snmp trap v3 engine-ID	configure
	no snmp trap v3 auth	configure
	no snmp trap v3 encryption	configure
	show snmp trap enable	configure
	show snmp trap host	configure
	show snmp trap version	configure
	show snmp trap community	configure
	show snmp trap inform retry	configure
	show snmp trap inform timeout	configure
	show snmp trap v3 user	configure
	show snmp trap v3 level	configure
	show snmp trap v3 engine-ID	configure
show snmp trap v3 auth	configure	
show snmp trap v3 encryption	configure	
FILE	copy running-config startup-config	configure
	copy startup-config running-config	configure
PORT MIRROR	monitor enable	configure
	monitor source [rx tx both] [port_list]	configure
	monitor destination [dest_port_number]	configure
	no monitor enable	configure
	no monitor source	configure
	no monitor destination	configure
	show monitor enable	configure
	show monitor source	configure
show monitor destination	configure	
QoS	qos queue-schedule [strict wrr]	configure

	qos map cos [priority_type] to tx-queue [queue]	configure
	qos map dscp [[priority_type] to tx-queue [[queue]	configure
	qos trust [cos dscp]	interface
	qos default cos [cos_default_value]	interface
	no qos queue-schedule	configure
	no qos map cos [priority_type]	configure
	no qos map dscp [priority_type]	configure
	no qos trust	interface
	no qos default cos	interface
	show qos queue-schedule	configure
	show qos map cos [priority_type]	configure
	show qos map dscp [priority_type]	configure
	show qos trust	interface
	show qos default cos	interface
IGMP	igmp snooping enable	configure
	igmp snooping query max-respond-time [1..12]	configure
	igmp snooping query interval [1..3600]	configure
	igmp snooping last-member count [2..10]	configure
	igmp snooping last-member interval [60..300]	configure
	igmp snooping querier enable	configure
	igmp snooping fast-leave enable	interface
	no igmp snooping enable	configure
	no igmp snooping query max-respond-time	configure
	no igmp snooping query interval	configure
	no igmp snooping last-member count	configure
	no igmp snooping last-member interval	configure
	no igmp snooping querier	configure
	no igmp snooping fast-leave	interface
	show igmp snooping mdb	configure
show igmp snooping all	configure	
show igmp snooping fast-leave	interface	
Trunk	trunk group [group] [static lacp] [interface_list]	configure
DHCP Server/Relay	dhcp service server	configure
	dhcp server included-address [IP_START] [IP_END]	configure
	dhcp server default-gateway [router_ip]	configure


	dhcp server name-server [dns_ip]	configure
	dhcp server lease [dhcp_lease_time]	configure
	dhcp server binding [bind_num][MAC] [bind_IP]	configure
	dhcp server port-binding [Port] [bind_IP]	configure
	dhcp service relay	configure
	dhcp relay server [server_number] [IP]	configure
	dhcp relay information option	configure
	dhcp relay information policy [replace keep drop]	configure
	dhcp relay untrust	interface
	no dhcp service server	configure
	no dhcp server included-address	configure
	no dhcp server default-gateway	configure
	no dhcp server name-server	configure
	no dhcp server lease	configure
	no dhcp server binding [bind_num]	configure
	no dhcp service relay	configure
	no dhcp relay server [server_number]	configure
	no dhcp relay information option	configure
	no dhcp relay information policy [replace keep drop]	configure
	no dhcp relay untrust	configure
	show dhcp service	interface
	show dhcp server status	configure
	show dhcp server included-address	configure
	show dhcp server default-gateway	configure
	show dhcp server name-server	configure
	show dhcp server lease	configure
	show dhcp server binding [bind_num][MAC] [bind_IP]	configure
	show dhcp relay enable	configure
	show dhcp relay server [server_number]	configure
	show dhcp relay information option	configure
	show dhcp relay information policy [replace keep drop]	configure
	show dhcp relay untrust	interface
UPnP	upnp enable	configure
	upnp advertisement interval [SEC]	configure
	no upnp enable	configure

	no upnp advertisement interval	configure
	show upnp enable	configure
	show upnp advertisement interval	configure
Modbus	modbus tcp server	configure
	no modbus tcp server	configure
	show modbus tcp server	configure
802.1X	dot1x enable	configure
	dot1x authentication server type [local radius]	configure
	dot1x authentication server 1 ip [IP]	configure
	dot1x authentication server 1 port [PORT]	configure
	dot1x authentication server 1 share-key [KEY]	configure
	dot1x authentication server 2 ip [IP]	configure
	dot1x authentication server 2 port [PORT]	configure
	dot1x authentication server 2 share-key [KEY]	configure
	dot1x local-db [USER] [PASSWORD]	configure
	dot1x authenticator enable	interface
	dot1x reauthentication enable	interface
	dot1x reauthentication period [SEC]	interface
	no dot1x enable	configure
	no dot1x authentication server type	configure
	no dot1x authentication server 1 ip	configure
	no dot1x authentication server 1 port	configure
	no dot1x authentication server 1 share-key	configure
	no dot1x authentication server 2 ip	configure
	no dot1x authentication server 2 port	configure
	no dot1x authentication server 2 share-key	configure
	no dot1x local-db [USER] [PASSWORD]	configure
	no dot1x authenticator enable	interface
	no dot1x reauthentication enable	interface
	no dot1x reauthentication period	interface
	show dot1x enable	configure
	show dot1x authentication server type	configure
	show dot1x authentication server 1 ip	configure
	show dot1x authentication server 1 port	configure
	show dot1x authentication server 1 share-key	configure

	show dot1x authentication server 2 ip	configure
	show dot1x authentication server 2 port	configure
	show dot1x authentication server 2 share-key	configure
	show dot1x local-db [USER] [PASSWORD]	configure
	show dot1x brief	configure
	show dot1x server brief	configure
	show dot1x brief	interface
	show dot1x server brief	interface
	show dot1x authenticator enable	interface
	show dot1x reauthentication enable	interface
	show dot1x reauthentication period	interface
IPv6	ipv6 enable	configure
	ipv6 address add [IPV6_ADDR</PREFIX_LEN>]	configure
	ipv6 neighbor flush	configure
	ipv6 ping [IPV6_ADDR] [<size PKG_SIZ> <repeat PKG_CNT>]	configure
	no ipv6 enable	configure
	no ipv6 address [IPV6_ADDR/PREFIX_LEN]	configure
	show ipv6 enable	configure
	show ipv6 address	configure
	show ipv6 neighbor	configure
TFTP	tftp upgrade	configure
	tftp server ip [IP_ADDRESS]	configure
	tftp file name [UPGRADE_FILE_NAME]	configure

Save and Load Configuration File to/from USB

1. CLI: enable -> configure terminal ->copy running-config usb (path)



```


ca. Telnet 192.168.2.19
User Access Verification
Username: admin
Password:
SWES> en
SWES# configure terminal
SWES(config)# copy
running-config startup-config usb
SWES(config)# copy running-config
startup-config usb
SWES(config)# copy running-config usb file1
SWES(config)# copy running-config usb /test/file2
SWES(config)# _

```

Fill in the folder and filename behind the “copy running-config usb” command.

Ex: file1, / folder /file2.

2. CLI : enable -> configure terminal ->copy startup-config usb (path)




```
ca. Telnet 192.168.2.19
User Access Verification
Username: admin
Password:
SWES> en
SWES# configure terminal
SWES(config)# copy
running-config startup-config usb
SWES(config)# copy startup-config
running-config usb
SWES(config)# copy startup-config usb file1
SWES(config)# copy startup-config usb /test/file2
SWES(config)#
```

Fill in the folder and filename behind the “copy startup-config usb” command.

Ex: file1, / folder /file2.

3. CLI :enable -> configure terminal ->copy usb startup-config (path)




```
ca. Telnet 192.168.2.19
User Access Verification
Username: admin
Password:
SWES> en
SWES# configure terminal
SWES(config)# copy
running-config startup-config usb
SWES(config)# copy usb
startup-config firmware
SWES(config)# copy usb
startup-config destination file
firmware destination file
SWES(config)# copy usb startup-config file1
```


Fill in the folder and filename behind the “copy usb startup-config” command.

Ex: file1, / folder /file2.

Upgrade via TFTP

CLI : enable -> configure terminal ->tftp server ip [IP_ADDRESS] ->tftp file name [UPGRADE_FILE_NAME] ->tftp upgrade



Fill in the TFTP server IP and upgrade file name behind the “tftp server ip [IP_ADDRESS]” and “tftp file name [UPGRADE_FILE_NAME]

7. Technical Specifications

Table 7.1 has the technical specifications for Antaira's LMP-1002C-SFP series: 10-port industrial gigabit PoE+ managed Ethernet switch, with 8*10/100Tx (PSE 30W/Port) and 2*Gigabit Combo Ports, (w/2*10/100/1000Tx RJ45 and 2*100/1000 SFP slots).

Standards	IEEE 802.3	10Base-T 10Mbit/s Ethernet
	IEEE 802.3u	100Base-Tx, 100Base-Fx, Fast Ethernet
	IEEE 802.3ab	1000Base-Tx Gigabit Ethernet
	IEEE 802.3z	Gigabit Fiber
	IEEE 802.3x	Flow Control for Full Duplex
	IEEE 8023.af	Power-over-Ethernet
	IEEE 802.3at	Power-over-Ethernet Plus (Enhanced)

	IEEE 802.3ad	Port Trunking with LACP
	IEEE 802.1d	STP (Spanning Tree Protocol)
	IEEE 802.1w	RSTP (Rapid Spanning Tree Protocol)
	IEEE 802.1s	MTP (Multiple Spanning Tree Protocol)
	ITU-TG.8032 / Y.1344	ERPS (Ethernet Ring Protection Switch)
	IEEE 802.1q	Virtual LANs (VLAN)
	IEEE 802.1x	Port based Network Control, Authentication
	IEEE 802.1ad	Stacked VLAN, Q-in-Q
	IEEE 802.1p	QoS/CoS Protocol for Traffic Prioritization
Switch	Protocol	IGMPv1/v2, SNMPv1/v2c/v3, TFTP, SNMP, SMTP, RMON, HTTP, HTTPS, Telnet, Syslog, DHCP Option 66/67/82, SSH/SSL, Modbus/TCP, LLDP, IPv4/IPv6
	Data Process	Store and Forward
	Transfer Rate	14,880 pps for 10Base-Tx Ethernet port 148,800 pps for 100Base-TX Fast Ethernet port 1,488,000pps for 1000Base-TxGigabit Ethernet port
	Packet Buffer	4 Mbits
	MAC Table	8K
	Jumbo Frame	-
	Flow Control	IEEE 802.3x full duplex mode, back pressure - half duplex mode
	VLAN Groups	1 ~ 4094
	IGMP Groups	Up to 256
Port Interface	Ethernet (RJ45) Port	8*10/100aseTx (PSE: 30W/Port) auto negotiation speed, Full/Half duplex mode, and auto MDI connection
	PoE Pin Assignment	V+, V+, V-, V-, for pin 1, 2, 3, 6 (Endspan, MDI Alternative A)
	Gigabit Combo Ports	2*10/100/1000Tx RJ45, and 2*100/1000 dual rate SFP Slots
	Wavelength	Refer to SFP Key Module
	Serial Console Port	1*RS232 in RJ45 connector with console cable, 115.2Kbps, 8,N,1
	Configuration Backup Port	1*USB 2.0
Protection	Overload Current	Present
	Power Reverse polarity	Present
	CPU Watch Dog	Present
	Network Cable	10Base-T: 2-pair UTP/STP Cat. 3, 4, 5 cable; 100Base-TX: 2-pair UTP/STP Cat. 5 cable. EIA/TIA-568 100-ohm (100m) 1000BaseTX: UTP/STP Cat.5/5E cable; EIA/TIA-568 100-ohm (100m)
Mechanical Characteristics	LED Indicator	Power Unit: P1 (Green), P2 (Green),fault(Red) Ethernet port: Link/active(Green), 1000Mbps SFP: Link/active(Green)

	Housing	Metal IP30 protection
	Dimension	54 x 142 x 99 mm
	Weight	Unit Weight: 2.4 lbs. Shipping Weight: 3.2 lbs
	Mounting	DIN-Rail Mounting, wall-mounting (optional)
Power Requirement	Input Voltage	48~55VDC Redundant Input
	Power Connection	1 removable 6-contact terminal block
	Power Consumption	15 Watts (no PD included); 145 Watts @12VDC; 200 Watts @24VDC
Environmental Limits	Operating Temperature	STD: -10° to 70° C (14° to 158° F); EOT: -40° to 75° C (-40° to 167° F)
	Storage Temperature	-40°C ~ 85°C (-40°F ~ 185°F)
	Ambient Relative Humidity	5 to 95%, (non-condensing)
Regulatory Approvals	EMI	FCC Class A
	EMS	IEC6100-4-2/3/4/5/6/8; IEC6100-6-2; IEC6100-6-4
	Stability Testing	IEC60068-2-32 (Free fall)
		IEC60068-2-27 (Shock) IEC60068-2-6 (Vibration)
Safety	UL 508 (Pending)	

Table 7.1 - LMP-1002C-SFP Series Technical Specifications

Antaira Customer Service and Support

(Antaira US Headquarter) + 844-268-2472

(Antaira Europe Office) + 48-22-862-88-81

(Antaira Asia Office) + 886-2-2218-9733

Please report any problems to Antaira:www.antaira.com / support@antaira.comwww.antaira.eu / info@antaira.euwww.antaira.com.tw / info@antaira.com.tw**Any changes to this material will be announced on the Antaira website.**